



Iomega ix2-dl Users Guide

D31593401

Table of Contents

Setting up Your Device	1
Setup Overview	1
Set up My Iomega StorCenter If It's Not Discovered	2
Discovering with Iomega Storage Manager	2
Discovering the Iomega device without the Internet	2
Setup Page	3
Network Connection	4
Connecting the Iomega StorCenter ix2-dl to Your Network	4
Network Settings	6
Manually Configuring the Network	7
Naming Your Iomega StorCenter ix2-dl	8
Configuring Your Iomega StorCenter ix2-dl to Use Active Directory	9
Enabling Active Directory Trusted Domains	9
Obtaining Alerts About Your Iomega StorCenter ix2-dl	11
Using Your Iomega StorCenter ix2-dl in Various Time Zones	12
Setting the Display Language for Your Iomega StorCenter ix2-dl	13
Printing Documents	14
Setting up Personal Cloud, Security, and File Sharing	15
Sharing Files	17
Sharing Overview	17
Interfaces for Sharing	17
Shares	18
What are Shares and How Do I Organize Content with Them?	18
Adding Shares	19
Managing Shares	20
Deleting Shares	22

- Using Protocols to Share Files 23
 - What Are Protocols and How Do I Use Them to Share Files? 23
 - AFP File Sharing for Macs 24
 - Bluetooth File Sharing 25
 - FTP File Sharing 26
 - NFS File Sharing 27
 - rsync: Synchronizing Files with Another Storage Device or Other Computers 28
 - TFTP 29
 - Monitoring Your Device with an SNMP Management Tool 30
 - WebDAV: Managing Files Using HTTP or HTTPS 31
 - Windows DFS: Creating a Distributed Windows File System 32
 - Windows File Sharing 33
- Sharing Your Content with the World 34
 - Deleting a Slideshow 34
- Automatically Sending Content to Multiple People at Once 35
 - How to Set Up an Email Distribution Active Folder 35
- Sharing Content using Social Media: Overview 36
- Managing Your Content 37
- Transferring Content to and from Your Iomega StorCenter ix2-dl with Copy Jobs 38
 - Copy Jobs Limitations 38
- Getting Content from a USB External Storage Device 39
 - Safely removing external storage 39
- iSCSI: Creating IP-Based Storage Area Networks (SAN) 41
 - iSCSI Overview 41
 - Adding iSCSI Drives 42
 - Enabling iSCSI Drives 42
 - Connecting to iSCSI Drives 42

Managing iSCSI Drives	44
Changing Access Permissions	44
Deleting iSCSI Drives	45
Storage Pool Management	47
Adding New Drives to Your Iomega StorCenter ix2-dl	47
Backing up and Restoring Your Content	49
Backup and Restore Overview	49
Backup of Data through RAID Protection	49
Backing up to and Restoring from Your Device	50
Backing up Macs with Time Machine	50
Copy Jobs Overview	51
Backing up Your Device	52
Copy Jobs	53
Mozy Backup	61
Restoring Folders with Mozy Backup	62
Amazon S3	63
Restoring Files with Amazon S3	64
Backing up with Iomega Personal Cloud	65
Restoring with Personal Cloud	66
Securing Your Device and Contents	67
What Is Security and Do I Need It?	67
Enabling Security and Creating an Administrator User	68
Disabling Security	68
Limiting Access to Your Content by Creating Users	70
Users	71
Users Overview	71
Adding Users	72

Managing Users	74
Deleting Users	76
Groups	77
Groups Overview	77
Adding Groups	78
Managing Groups	79
Deleting Groups	80
Using Active Directory Domain to Manage Users and Groups	81
Active Directory Users and Groups Overview	81
Managing Users and Groups with Active Directory	82
Deleting Active Directory Users and Groups	84
Personal Cloud: Accessing Your Device From Anywhere in the World	85
What Is an Iomega Personal Cloud ?	85
Iomega Personal Cloud Key Terms	85
Is My Content Secure?	87
Iomega Personal Cloud Setup Overview	88
Creating an Iomega Personal Cloud	89
Configuring Router Port Forwarding for Personal Cloud	90
Router Port Forwarding	90
Configuring Your Iomega Personal Cloud	92
Enabling Internet Access to the StorCenter ix2-dl	92
Changing Personal Cloud Settings	92
Inviting People onto Your Iomega Personal Cloud	93
Joining a Trusted Device to an Iomega Personal Cloud	94
Managing Trusted Devices on a Personal Cloud	95
Disconnecting Trusted Devices	95
Deleting Trusted Devices	95

Using Copy Jobs with an Iomega Personal Cloud	96
Disabling or Deleting Your Iomega Personal Cloud	97
Accessing Content Using Your Iomega Personal Cloud	98
Informing Users What to Do with Iomega Personal Cloud	99
Sharing Content Using Social Media	101
Sharing Content using Social Media: Overview	101
Facebook	102
Flickr	103
YouTube	104
Share Content through Iomega Personal Cloud.....	105
Media Management	107
Media Management Overview	107
Scanning for media content.....	107
Media Services Capabilities and Limitations	108
Sharing Media Content over the Internet.....	109
Enabling Internet Access from the Media Server Page	109
Media Aggregation	110
Social Media Sharing	111
Streaming Music, Movies, and Pictures	112
Example: Setting up iTunes	112
Example: Setting up Xbox 360	112
Photos	113
Photos Overview	113
Streaming Pictures.....	114
Creating a Slideshow on the Device Home Page	115
Automatically Resizing Your Photos	116
Getting Pictures from Your Camera	117

Music	118
Music Overview	118
Streaming Music	119
Torrents	120
Torrent Overview	120
Enabling Torrent Downloads	121
Deleting torrent jobs	122
Configuring Your Router for Torrent Downloads	123
Torrent Active Folders	124
Videos.....	126
Video Capabilities Overview	126
Streaming Movies	127
Video Surveillance	128
Adding Applications to Your Device	135
Application Overview	135
Application Manager	136
Starting or stopping an application	136
Adding applications.....	136
Removing applications	136
Upgrading Your Device	137
Software Updates.....	137
Auto-update process: installing a device software update.....	137
Manual update process: installing a device software update	137
Recovering Your Device Configuration.....	139
Copying Your Iomega StorCenter ix2-dl Settings to Other Devices	139
Backing up Device Configuration.....	139
Restoring a Configuration Backup.....	139

Hardware Management	141
About the StorCenter ix2-dl Components	141
Front Panel.....	141
Rear Panel.....	141
Energy Saving.....	143
Power Down Drives	143
Brightness	143
Factory Reset.....	144
UPS Management	145
Adding New Drives to Your Iomega StorCenter ix2-dl	146
Troubleshooting Routers	147
Enabling the DMZ	147
Configuring Port Forwarding on Double NAT Networks	147
Bridging the Secondary Router	148
Bridging the Primary Router	148
Additional Support	151
How to Get Help	151
Support	152
Legal	153
StorCenter ix2-dl Trademark Page	153
Regulatory Information	154
FCC (United States).....	154
Canadian Verification	154
CE (European Community)	155
Manufacturer/Responsible Party	155
EU Representative	155
Safety Information.....	156

Limited Warranty	157
Drives and Media	157
Coverage	157
Excluded Products and Problems.....	157
Remedies	157
Obtaining Warranty Service	157
Limitations	158
Open Source	159

Setting up Your Device

Setup Overview

Setup with your Iomega StorCenter ix2-dl is easy. Remove it from the box, connect it to your network or computer, and power it up. Then, launch a web browser, and enter the setup URL identified in the Quick Install Guide. Iomega Setup launches and displays a message that your StorCenter ix2-dl is online and ready to use.

You then can install client software that includes:

- Iomega Storage Manager
- Twonky Media Server for media aggregation
- Iomega QuikProtect for backups

Iomega Storage Manager is a management tool that helps you discover your StorCenter ix2-dl on your network to simplify access to content on your StorCenter ix2-dl from your computer and allows you to add your computer as a trusted device to an Iomega Personal Cloud . Refer to Iomega Storage Manager online help for additional information. Twonky Media Server consolidates all media files on devices on your network and presents them in a unified view. Iomega QuikProtect offers file backup of your computer to an Iomega storage device.

From Iomega Setup, you can optionally create a Personal Cloud or begin using your StorCenter ix2-dl by clicking **Manage My Device**.

How do I ...

[set up my StorCenter ix2-dl if it's not discovered](#)

[create an Iomega Personal Cloud](#)

[set up media aggregation](#)

Set up My Iomega StorCenter If It's Not Discovered

If, after you enter the setup URL identified in the Quick Install Guide, your Iomega device is not discovered, you have two ways of discovering it.

Discovering with Iomega Storage Manager

You can [install Iomega Storage Manager](#) from Iomega Setup, which helps you discover your Iomega device on your network.

Discovering the Iomega device without the Internet

You can access your Iomega device without internet access as described by these methods for Windows PCs or Macs:

- **Windows 7 and Vista** — Click **Start, Computer, Network**. Under Other Devices, you should see your Iomega device listed. For example, if you have an EZ Media device, you can double-click the device labeled IomegaEZ, and you will see the Iomega StorCenter Console for the Iomega device .
- **Windows XP** — If you have not enabled UPnP Discovery, click **Start, Help and Support**. In the Help and Support browser, search for **UPnP**, and follow the steps from "Install the UPnP framework". After UPnP is enabled, open Windows Explorer and in the Folders view, expand My Network Places. You should see your Iomega device listed. For example, if you have an EZ Media device, you can double-click the device labeled IomegaEZ, and you will see the Iomega StorCenter Console for the Iomega device .
- **Mac** — Browse to your Iomega device through **Finder, Shared, All** and use **Go, Connect to Server** to connect to Shares on your Iomega device .

How do I ...

[set up my Iomega device](#)

[install Iomega Storage Manager](#)

Setup Page

The Setup page opens when you first access the Iomega StorCenter ix2-dl from the Home Page or the Iomega Storage Manager . On this page, you can configure some basic device features by clicking the appropriate link. The current setting of the feature displays above the link. You can also configure all features shown on the Setup page by accessing the specific features directly.

Network Connection

Connecting the Iomega StorCenter ix2-dl to Your Network

First, check the package contents.

Verify that the box contains the following items:

- StorCenter ix2-dl (models may vary)



- Power Cable
- Quick Start Guide



- Ethernet Cable



Package contents may vary.

Connecting the StorCenter ix2-dl

Initial Setup

If you have purchased more than one StorCenter ix2-dl , complete all steps on one device before setting up additional devices.

1. Use the included network cable to connect the StorCenter ix2-dl to a network hub, switch or directly to a computer.
2. Connect the included power cord to the back of the StorCenter ix2-dl and a power socket or Uninterruptible Power Supply (UPS).
3. Your StorCenter ix2-dl should power on automatically.

4. Start your computer and wait for the operating system to load.
5. For best results, use a computer that is connected to the same router, hub, or switch as the StorCenter ix2-dl .
6. OPTIONAL: if desired, install the Iomega Storage Manager , QuikProtect, and Media Aggregation software.

If you install the Iomega Storage Manager , its icon will appear in the System Tray (Windows) or Menu Bar (Mac). The Iomega Storage Manager will automatically scan your network and connect to available Shares.

If you receive a message from your operating system's firewall alerting you of network activity, be sure to unblock communications.

Mac Users: Shares on the StorCenter ix2-dl will mount and appear on the Mac Desktop.

PC Users: Shares on the StorCenter ix2-dl will automatically be assigned a drive letter and will be available in the Network Drives section under My Computer.

Network Settings

The Network page of your StorCenter ix2-dl is where you make changes to set up network connectivity. The Network page displays your current network settings and enables those settings to be modified. On this page, you can identify your DNS servers and WINS servers and how your system's IP address is determined. Most system IP addresses and other network settings can normally be configured automatically.

Manually Configuring Your Network

If you are comfortable with network technology and want to configure the network, refer to [Manually Configuring the Network](#).


Enabling Jumbo Frames for Each NIC

You can enable jumbo frames for each NIC in your StorCenter ix2-dl by expanding the **Information** section for a NIC and selecting a jumbo frame size from the **Jumbo Frame** drop-down menu. Valid jumbo frame sizes are 4,000 or 9,000 bytes. If you do not want jumbo frame support, select **None** from the **Jumbo Frame** drop-down menu. Jumbo frame support is useful for transferring large files, such as multimedia files, over a network. Jumbo frame support increases transfer speed by placing large files in fewer data packets. It also reduces the demand on the device hardware by having the CPU process more data in fewer data packets.

Jumbo frame support should only be enabled if you are sure your network is jumbo-frame compatible and all network devices have been configured to support jumbo frames. It is recommended that you confirm all network interface cards (NICs) are configured to support jumbo frames before enabling this feature.

Manually Configuring the Network

There are various settings in the network setup that you can manually configure.

1. Click  **Modify network settings**.
2. Uncheck **Automatically configure DNS, WINS, and all IP addresses (DHCP)**.
3. **DNS Servers** – enter the IP addresses of the DNS (Domain Name System) servers. DNS is used for translating the domain name to IP addresses.
4. **WINS Servers** – enter the IP addresses of the WINS server.
5. From the **Bonding Mode** drop-down menu, choose one of the following:
 - **Transmission Load Balance** – increases bandwidth by distributing the load across multiple NICs.
 - **Link Aggregation** – increases bandwidth by distributing the load across multiple ports in a switch.
 - **Failover** – provides recovery from a failure, so if one NIC should fail, your system still has network connectivity with the other NIC.
6. Click **Apply** to save your settings.

If a DHCP server is unavailable for a network interface card (NIC), the device could auto-assign an IP address, or you can uncheck the **Automatically acquire network address (DHCP)** checkbox found in the **Information** section of a NIC.

7. You can change the following settings in the **Information** section:
 - **IP Address** – the static IP address of the StorCenter ix2-dl . Use an available IP address in the range used by the LAN.
 - **Subnet Mask** – the subnet that the IP address belongs to. The default value is 255.255.255.0.
 - **Gateway** – enter the gateway IP address in this field.
8. Click **Apply** to save your settings.

Naming Your Iomega StorCenter ix2-dl

You can provide a meaningful name for your StorCenter ix2-dl using the Device Identification page. This page in the Iomega StorCenter ix2-dl Console enables you to change the Storage Device Name, the Storage Device Descriptive Name, and the Workgroup Name.

Change any of these by editing the text fields. Click **Apply** to save your changes.

Device Name

Enter a name for the Iomega device. Use a name that will help you identify it on your network.

Device Descriptive Name

Enter a descriptive name for the Iomega device. This name can provide additional detail that identifies the device.

Workgroup Name

Enter a workgroup name for the Iomega device if you need to change the default name. The workgroup name identifies a group of computers that share information with each other. Change the workgroup name only if you explicitly define a workgroup on your network. Most users won't need to change the workgroup name, unless they have explicitly defined a different workgroup on their other computers.

How do I...

[enable security](#)

Configuring Your Iomega StorCenter ix2-dl to Use Active Directory

If you have an existing Active Directory user organization, you can incorporate it into the Iomega StorCenter ix2-dl Console .

Note: When you configure Active Directory, you [enable security](#) on your StorCenter ix2-dl .

1. To configure Active Directory, manually add the StorCenter ix2-dl to your DNS server. Set the StorCenter ix2-dl DNS setting to point to your DNS server. On the Network page, uncheck **Automatically configure all network settings**, type the IP address of your DNS Server in the text box, and click **Apply** to save your settings.
2. Configure the StorCenter ix2-dl to join the Active Directory domain. **Active Directory** – select Active Directory mode if you already have an existing user organization, such as Active Directory, that you want to incorporate into the StorCenter ix2-dl .
3. Provide the following connectivity information:
 - **Domain Name** – the actual name of your Active Directory domain, for example, sohead.com .
 - **Domain Controller** – the actual name or IP address of your Active Directory Server, for example, ad-server.sohoad.com or 10.14.50.12.
 - **Organizational Unit** – an optional predefined subset of directory objects within an Active Directory domain.
 - **Administrator Username** – the Active Directory username with domain administrator privilege.
 - **Administrator Password** – the Active Directory password for the specified Active Directory username.
 - **Users/Groups Refresh Interval** – how often the StorCenter ix2-dl should refresh the list of available users and groups from the Active Directory server.
 - **Enable Trusted Domains** – enables your StorCenter ix2-dl to allow access to other domains.
4. Click **Apply** to save your settings.

Enabling Active Directory Trusted Domains

By enabling Active Directory trusted domains on your StorCenter ix2-dl , you enable the importing of users and groups from other trusted domains to your StorCenter ix2-dl device. Those users and groups from other domains will then have access to features on your StorCenter ix2-dl , including accessing folders and documents in Shares, and joining any Personal Cloud of which the device is a member.

Now that you have enabled access to all trusted domains, you can add users and groups from those trusted domains to your StorCenter ix2-dl . For more information, refer to [Manage Users and Groups with Active Directory](#).

How do I ...

[enable security](#)

Obtaining Alerts About Your Iomega StorCenter ix2-dl

You can configure your StorCenter ix2-dl to send email alerts when problems are detected. This is done through the email notification feature. Email notification provides a destination for emails sent by the StorCenter ix2-dl when problems are detected. To provide a destination email address, enter the following information:

- **Destination Email Addresses** – enter a valid email address or addresses. This email address provides a destination for messages sent by the StorCenter ix2-dl when problems are detected by the system.
- Check **Send a test email message** to confirm that email notification is working properly.
- Check **Configure custom SMTP settings** only if your network blocks SMTP traffic, requiring additional credentials, such as a corporate firewall. Most users will not need to check this option. If checked, enter the following additional information to identify your SMTP server:
 - **Email Server (SMTP)** – enter the address of your SMTP server.
 - **Sender Email Address** – enter an email address for the StorCenter ix2-dl to use as the *From* address when it creates messages.
 - **Email Login** – enter the username used to log into the email account you entered above.
 - **Email Password** – enter the password for the email account.
 - **Confirm Password** – confirm the password for the email account. It must match the password provided above.

Note: If your email application uses a SPAM blocker, it is recommended that you add a sender email address to your safe list. If you do not define additional credentials, the default sender email is: `sohostorage@emc.com`

Click **Apply** to save your changes.

Using Your Iomega StorCenter ix2-dl in Various Time Zones

You can set the date and time used on your StorCenter ix2-dl , so that it can appear to be in one time zone, when it actually may be in a different one. This can help your users have the correct date and time if they live and work in a location different from your StorCenter ix2-dl . You can set the date, time, and time zone through the Date and Time feature.

Note: When an Active Directory Domain is in use, the storage device synchronizes time with the domain controller.

1. To change time zones, select a Time Zone from the drop-down menu, and then select how time will be set for the StorCenter ix2-dl :

Internet Time Server

By default, Automatically synchronize with an internet time server and Use the default time server are selected. To specify a time server, select Specify the time server and type the URL of the internet time server you wish to use in the text box that displays.

Manual

Select Manually set date and time. To set the current date and time, click the appropriate icon for calendar and clock settings.

2. Click **Apply** to save your changes.

Setting the Display Language for Your Iomega StorCenter ix2-dl

You can set the display language for your StorCenter ix2-dl through the Languages page.

The Languages page allows you to change the language used in email notification messages.

The language used by the Iomega StorCenter ix2-dl Console is based on the preferences configured in your browser. You can change the language used in this program by modifying your browser's preferred language settings.

Click **Apply** to save your changes.

Printing Documents

Printing documents from your Iomega StorCenter ix2-dl is simple after you have attached a compatible printer to the StorCenter ix2-dl . The Printers page displays a table of printers that are attached to the StorCenter ix2-dl . The table contains for each printer the name, model, status, and number of documents waiting.

To attach a printer, simply plug a supported printer's USB cable to a USB port on the StorCenter ix2-dl . Once attached, the printer will appear in the table. When the cable is unplugged, the printer will be removed from the table.

Setting up Personal Cloud, Security, and File Sharing

After you have configured some basic features of your Iomega StorCenter, you may also want to set up an Iomega Personal Cloud, security, or file sharing.

You can set up a Personal Cloud to allow invited users access to content on your Iomega StorCenter. This content can be in private Shares that are exclusive to the users who join the Personal Cloud, which adds an additional layer of security to your content. In addition, you may want to join other trusted devices to the Personal Cloud so that content on those devices can be made available to Personal Cloud users. For more information about Personal Clouds, refer to the [Personal Cloud overview](#).

You can enable security so you can secure Shares, create users, and allow selected features to be enabled. When you create users, you limit access to your Iomega StorCenter to those specific people, and when you secure Shares, you limit data access to those specific users. For more information on security, refer to [What Is Security and Do I Need It?](#)

It is recommended to set up file sharing so that content can be added to your Iomega StorCenter, and that content can be made available in a wide variety of ways, including users of your Iomega StorCenter and content features such as Active Folders and media sharing. For more information, refer to the [Sharing Overview](#).

How do I ...

[create an Iomega Personal Cloud](#)

[set up security](#)

[set up file sharing](#)

Sharing Files

Sharing Overview

Your Iomega StorCenter is set up for storing, retrieving, and accessing files among users, client computers, and applications.

Note: File sharing is accomplished by creating Shares; setting up security, which includes creating users; setting up media services; and configuring Active Folders.

Interfaces for Sharing

Your Iomega device has three separate interfaces for file sharing:

Iomega StorCenter Console

You manage the creation of Shares through the Iomega StorCenter Console .

Iomega Storage Manager

Optionally installed on your local computer, the Iomega Storage Manager discovers any Iomega storage devices on your subnet, maps device Shares to computers, and provides local access to your content. It provides access to Shares through your computer's file management program, such as Windows Explorer or Mac Finder, allowing you to drag and drop many files between your computer and the Iomega device . Installing the Iomega Storage Manager is optional.

Home Page

Serves as a web-accessible interface to your Iomega device . The Home page content is configured using the Iomega StorCenter Console . The Home Page displays any public Shares. It can also display secured Shares accessible only to users who log in to the Iomega device . You can access the Home page of your Iomega device by entering the device name or IP address directly in your browser. If security is enabled and you are an administrator user, you can access the Iomega StorCenter Console

from the Home page by clicking  .

How do I ...

[create Shares](#)

[enable security](#)

[create users](#)

Shares

What are Shares and How Do I Organize Content with Them?

Shares are folders that contain all types of content, including documents, pictures, and music files. Shares can be public, meaning anyone accessing your StorCenter ix2-dl can access the content in the Shares. Shares can also be secured, which means access to content in them is limited to a select group of users.

All Shares on an StorCenter ix2-dl are displayed on the Shares page. The Shares page displays a table that contains folders, connected drives, and any cloud storage to which your Iomega StorCenter ix2-dl Console is connected. The Properties column displays the features that are enabled for each Share.

Share Information

The Information section displays the Share name, graphically displays the space usage of the Share, and allows you to view the content using the web-based content viewer.

To view the content of a Share, click **View Content** to open the Content Viewer.

To learn how to modify your Share information, refer to [Managing Shares](#).

Access Permissions

The Access Permissions section contains a list of [users](#) who currently have access to that Share. Access Permissions displays when the StorCenter ix2-dl is [secured](#), otherwise the section is not included in the Share. If "Everyone" has access to Shares that means your content can be viewed by anyone with access to your network without that person needing a username or password.

To learn how to modify Access Permissions on a Share, refer to [Managing Shares](#).

Active Folders

Follow the link to the Active Folder options for information on configuring each:

- [Email Distribution](#)
- [Facebook](#)
- [Flickr](#)
- [Photo Resize](#)
- [Torrents](#)
- [YouTube](#)


How do I...

[add a Share](#)

[manage a Share](#)

[delete a Share](#)

Adding Shares

1. From the Iomega StorCenter Console , click **Shares**.
2. To add a new Share, click  **Add a Share**. Type a name for the Share. All Shares must have a name. Names cannot exceed 32 characters. The following are not valid Share names: global, homes, printers
3. Click **Create**. To modify an existing Share, click the Share row to expand the Share.

How do I ...

[manage Shares](#)


[delete Shares](#)

Managing Shares

You can change Share information, change access permissions, make a Share an Active Folder, use Share volumes, and modify a Share volume.



If available, you can also enable NFS secured access.

Changing Share Information


1. Modify the existing name for the Share.
2. Choose whether to enable media sharing. When Media sharing is enabled, the media server scans this Share for any media content and makes it available to anyone with access to your network, even if this Share is secured. If you do not want media content made available to anyone, do not check this option. When Media sharing search is enabled,  displays in the Properties for that Share.
3. To view the content of a Share, click the **View Content** link to open the Content Viewer.
4. Click **Apply** to save your changes.

Changing Access Permissions



Note: You should [enable security](#) on your Iomega StorCenter before changing access permissions.

1. Expand **Access Permissions** to change user permissions to this Share. A security icon  displays in Properties indicating a secure Share. When a secure Share is first created, Everyone has read and write access to that Share by default, which means that everyone on your network can read, write, and delete files to and from that Share. When user Everyone has Read and Write permissions to a Share, the Share is not secure and is open to all users.
2. Check **Allow users to change file level security** to allow file and folder permissions to be set through other programs, such as Windows Explorer, independent of the Iomega device. Setting this option allows users to put additional access restrictions on individual files and folders.
3. To limit access to this Share to a specific set of users, click  **Add access permissions** and choose one or more users from the pop-up window. If you have created groups, you can also limit access for them in this way.
4. In the **Access Permissions** section, check Read, Write, or both to set access to this Share for each user. To remove a user, leave both Read and Write unchecked for that user. If you grant Read and Write permissions to Everyone, the list of users is also cleared since all users (Everyone) has access to this Share. If you have created groups, you can also limit access for them in this way.
5. Click **Apply** to save your changes.

Enabling NFS Secured Access

1. To enable [NFS](#), first click the switch on from the Protocols page.
2. On the Shares page, select a secure Share and expand the NFS section. You cannot apply a rule to a public Share.
3. Click  **Add an NFS rule** to add a **Host Name** for the rule. Rules are added to specify the hosts that are allowed to access Shares using NFS. Use this table to add NFS rules to specify access for hosts. For example, *.cs.foo.com matches all hosts in the domain cs.foo.com. To export a Share to all hosts on an IP address or local network simultaneously, specify an IP

address and netmask pair as address/netmask where the netmask can be in dotted-decimal format, or as a contiguous mask length. For example, either /255.255.252.0 or /22 will result in identical local networks.

4. When the rule is added, read access is automatically set to the Share. Select **Write** to allow users to write to that Share. Use  and  to modify the rule priority for NFS access.
5. Click **Apply** to save your changes.

Making a Share an Active Folder

1. You can optionally enable Active Folders on a Share to allow you to associate this Share with a specific feature that will happen automatically when files are copied to the Share. For example, you can enable a Share as a social media active folder to upload a file to a social media site. Refer to [Sharing Content with Social Media Overview](#) . You can only set one Active Folder option per Share.
2. Expand the **Active Folder** section and check **Enable**. Select one of the following Active Folder options and follow the link for details on configuring each:
 - [Email Distribution](#)
 - [Facebook](#)
 - [Flickr](#)
 - [Photo Resize](#)
 - [Torrents](#)
 - [YouTube](#)
3. Click **Apply** to save your changes.

How do I ...

[add a Share](#)

[delete a Share](#)

[share content with social media](#)

Deleting Shares

To delete a Share:

1. From the Iomega StorCenter ix2-dl Console , click **Shares**.
2. To delete an existing Share, click to expand the Share.
3. In the Information section, click **Delete** to delete the Share.
4. In the **Delete Share** confirmation pop-up window, click **Yes**.
5. If you do not wish to delete the Share, click **Cancel** to return to the Shares page.

How do I ...

[add a Share](#)

[manage a Share](#)

Using Protocols to Share Files

What Are Protocols and How Do I Use Them to Share Files?

Your Iomega StorCenter ix2-dl uses communication protocols to mount file systems and allow files to be transferred between client computers and the Iomega StorCenter.

The StorCenter ix2-dl includes the following protocols for file sharing:

- [AFP](#)
- [Bluetooth](#)
- [FTP](#)
- [TFTP](#)
- [NFS](#)
- [rsync](#)
- [SNMP](#)
- [WebDAV](#)
- [Windows DFS](#)
- [Windows File Sharing](#)

AFP File Sharing for Macs


The Apple Filing Protocol (AFP) enables Apple file sharing, which is the preferred method for Mac users to access Shares. AFP is on by default.


To enable AFP, click the switch on.

Bluetooth File Sharing

Once a Bluetooth adapter is detected, files can be uploaded to a configurable destination Share on the StorCenter ix2-dl from a Bluetooth device.


Configuring Bluetooth settings

1. To enable Bluetooth, click the switch on.
2. Once Bluetooth Transfer is enabled, check the **Enable security** checkbox to require Bluetooth users to supply a unique PIN that they have defined before allowing them to transfer files to the destination Share on the StorCenter ix2-dl . If you have [enabled security](#), you must define a unique PIN number, which will be supplied by devices attempting to upload data using Bluetooth.
3. To set the destination Share, click .
4. Click **Apply** to save your settings.

Note: To change any Bluetooth settings, click .

FTP File Sharing

On the Protocols page, click the switch to turn on FTP (File Transfer Protocol) and allow access to your Iomega StorCenter ix2-dl .

Click  to select either FTP or secure FTP (SFTP) or both. You must [enable security](#) to apply SFTP. If you select and enable SFTP, you cannot have the [secure Rsync protocol](#) enabled.

When you turn on FTP, you can send files to your StorCenter ix2-dl .

NFS File Sharing


On the Protocols page, click the switch to turn on NFS (Network File System) to allow remote hosts to mount file systems over a network and interact with them as though they were mounted locally to your Iomega StorCenter ix2-dl .

Note: Select an option to choose how users on client computers are mapped to the StorCenter ix2-dl :

- To have all users, including root, map as guest, select **Treat client users as guest (all_squash)**. All files are owned by user guest, and all users accessing the StorCenter ix2-dl have the same access rights. If you have enabled Active Directory on your StorCenter ix2-dl , only this option is available for mapping client computers.
- To have all users map as themselves but root maps as guest, select **Allow full access for client users other than root (root_squash)**.
- To have all users map as themselves, including root, select **Allow all client users full access**.

Once enabled, add NFS access rules for each secure Share from the [Managing Shares](#) page. NFS provides another protocol for sharing storage data with Linux hosts. When NFS is enabled, you can configure rules for host-based access to secure Shares.

Rules can be added to secure Shares to specify the hosts that are allowed to access Shares using NFS. For example, *.cs.foo.com matches all hosts in the domain cs.foo.com. To export a Share to all hosts on an IP address or local network simultaneously, specify an IP address and netmask pair as address/netmask where the netmask can be in dotted-decimal format, or as a contiguous mask length. For example, either /255.255.252.0 or /22 will result in identical local networks.

To change any NFS settings, click  .


rsync: Synchronizing Files with Another Storage Device or Other Computers

When you turn on this protocol, you can enable the Iomega StorCenter ix2-dl as an rsync server. When the StorCenter ix2-dl is an rsync server, it can be used as a source and/or destination device for rsync Copy Jobs. Because of the fast and efficient nature of rsync, an rsync Copy Job can be faster than a Windows File Sharing Copy Job. For more information on Copy Jobs, refer to [Copy Jobs](#).

If you enable the StorCenter ix2-dl as an rsync server, you can optionally set up a user account on the StorCenter ix2-dl for secure rsync Copy Jobs.

Configuring rsync server settings

1. To enable rsync server, click the switch on.
2. To create a secure user account, check **Configure secure rsync credentials**. The username is preset as rsync. Enter a password and confirm it for the rsync username. When you create a secure rsync user account on the StorCenter ix2-dl, you allow other devices to securely copy to or from it.
3. Click **Apply** to save your settings.

Note: To change any rsync server settings, click . You cannot enable rsync server if you have already enabled [SFTP](#).

TFTP

On the Protocols page, click the switch to turn on TFTP (Trivial File Transfer Protocol) and allow access to your Iomega StorCenter . When you turn TFTP on, you can send files to your Iomega device using FTP.

Monitoring Your Device with an SNMP Management Tool

SNMP (Simple Network Management Protocol) provides information about the state of the Iomega StorCenter ix2-dl to various management tools.

SNMP should be disabled unless you are specifically providing information to a management system that requires this information.

Configuring SNMP settings

1. To enable SNMP, click the switch on.
2. Enter a unique username and password to define the community.
3. Confirm your password.
4. Enter the IP address of the host in the **Trap Receivers** text box. To grant access to multiple receivers, list all of them in the text box, separating each entry with a space.
5. Click **Apply** to save your settings.

To change any SNMP settings, click  .

WebDAV: Managing Files Using HTTP or HTTPS

WebDAV (Web-based Distributed Authoring and Versioning) is a protocol that provides web-based access to Shares on the Iomega StorCenter ix2-dl . With WebDAV enabled on the StorCenter ix2-dl , you can view, add, or delete files through your WebDAV client using either HTTP for unencrypted access or HTTPS for encrypted access. HTTP offers faster performance, but is not secured. Access Shares using a URL such as `http://devicename/WebDAV/Foldername`. Refer to your operating system's documentation to learn how to access files through WebDAV.

Note: If your StorCenter ix2-dl has a remote access password, you must enter that password and the username `webdav` to access your device. Your StorCenter ix2-dl has a remote access password only if the device is not secured and a [Personal Cloud was created on it](#).

Configuring WebDAV settings

1. To enable WebDAV, click the switch on.
2. To enable WebDAV for HTTP, check **Enable WebDAV Over HTTP**.
3. To enable WebDAV for HTTPS, check **Enable WebDAV Over HTTPS**.
4. Click **Apply** to save your settings.

Windows DFS: Creating a Distributed Windows File System

Windows DFS (Distributed File System) organizes Shares and files on a network, such that they appear to be all in one directory tree on a single StorCenter ix2-dl , even if the Shares reside on many devices.

Windows DFS terms

There are several terms to understand with Windows DFS.

Namespace

A virtual Share containing other folders that are located on different devices throughout a network.


DFS root

An object that consolidates all the folders in your network and makes them available through a single entry point. An example of a DFS root is \\ DeviceName\DFSRootName.

DFS link

A folder under the DFS root.

Configuring Windows DFS settings

1. To enable Windows DFS, click the switch on.
2. Enter a DFS root name. The DFS root name is the starting point of a DFS namespace.
After entering a DFS root name, you add DFS links, which map to folders on other devices.
3. Click  Click to add a DFS link target to begin adding DFS links.
4. Enter the DFS link name, which includes the name of the host and Share to which you are linking.
5. Click **Apply** to save your settings, or click **Cancel** to discard your changes.

Windows File Sharing

Windows File Sharing allows you to work in Workgroup mode, using Iomega StorCenter ix2-dl Console to create users and manage access. To enable Windows File Sharing, click the switch on.


Sharing Your Content with the World

When you set up the Home Page of your Iomega StorCenter ix2-dl , you are presenting public content to anyone who accesses your StorCenter ix2-dl . That public content includes a slideshow and public Shares.

You can manage the look of the Home Page by using the Home Page Settings page. This page allows you to display the slideshow, display public Shares, name the Home Page, and turn the Home Page on or off.

1. From the Iomega StorCenter ix2-dl Console , click **Home Page Settings**.
2. Click the slider switch to On to enable the Home Page on your StorCenter ix2-dl .
3. Enter a title for the Home Page. This title displays in the top banner of the Home Page when users access the StorCenter ix2-dl .
4. Check **Display Shares** to display public Shares. When you select to display Shares, the user sees all public Shares on the StorCenter ix2-dl .
5. Check **Display slideshows** to display picture slideshows that are in folders on the StorCenter ix2-dl . Click **Manage slideshows** to configure any slideshows you want to display. The slideshow location can be any folder attached to the StorCenter ix2-dl , including a USB drive or [DFS location](#).
6. Click **Apply** to save your changes, or click **Cancel** to discard your changes.

Deleting a Slideshow

To delete a slideshow from the list of available slideshows, click  . After you delete a slideshow, you can configure a different one.

How do I...

open the Iomega StorCenter ix2-dl Console

[create Shares](#)

Automatically Sending Content to Multiple People at Once

You can send content to multiple people at once using an email distribution active folder. You can configure a [Share](#) as an Email Active Folder so that when you add files to that Share, they are automatically sent to the recipients on the email distribution list. To configure a Share as an Email Active Folder, access Shares from the Iomega StorCenter ix2-dl Console, select or create a Share, and expand the Active Folders section to enable and configure email distribution.

How to Set Up an Email Distribution Active Folder

Note: Email Distribution lets you email your files to friends and family right from your Iomega StorCenter ix2-dl Console. Use Email Distribution to share files with an email list.

Note: To prevent email distribution list spamming, the StorCenter ix2-dl allows lists of 250 or fewer email recipients and sends a maximum of six emails in a 24-hour period.

Refer to [Managing Shares](#) for more information on managing Shares and Active Folders.

Configuring an Email Distribution Active Folder

1. From the Iomega StorCenter ix2-dl Console, click **Shares**.
2. Select a Share to use as an Email Distribution Active Folder, and click to expand the Active Folder section.
3. Check **Enable**.
4. Select **Email Distribution** from the drop-down menu.
5. Include an email address in the **Sender Email Address** text box. Distribution is sent from this email address.
6. You can add multiple email addresses in the **Email To:** text box by separating them with commas, spaces, or semicolons.
7. Add a subject and email message for your recipients.
8. Check **Send the file as an attachment**, **Send a link to the file**, or both.
9. Click **Apply** to save your changes.
10. Once configured, all files in this Share are sent by email to your recipients. Click **View Transfer History** to see the transfer activity from this Share to your account.

How do I...

[manage a Share](#)

Sharing Content using Social Media: Overview

If you have an account with social media services such as Facebook, Flickr, or YouTube, you can share content on your Iomega StorCenter ix2-dl with your friends and family using one or more of these social media sites. To share your content using social media sites, create Shares called [Active Folders](#), and connect each Active Folder with a social media account. Refer to the help topic links below for more information on these procedures. When you add photos and movies to an Active Folder, those files are automatically uploaded to the social media site associated with that Active Folder. If you have photos or movies you want to share with others, this is a great way to make your content available to people who may not have access to your StorCenter ix2-dl .

If you have configured a Personal Cloud on your StorCenter ix2-dl , you can grant Personal Cloud users access to Shares and Active Folders. This is useful if you want to allow users to add files to your social media sites. For example, if your StorCenter ix2-dl has a Flickr Active Folder, you can grant Personal Cloud users access to that Active Folder. In this manner, when photos are added to the Flickr Active Folder, either by you or by Personal Cloud users, those photos are uploaded automatically to your Flickr account.

Note that an Active Folder can only be associated with one social media account. For example, if you want Active Folders for your Facebook and YouTube accounts, create two Active Folders, and assign one Active Folder to Facebook, and one to YouTube. Using this example, any photos you add to your Facebook Active Folder are automatically uploaded to your Facebook page, and any movies you add to your YouTube Active Folder are automatically uploaded to your YouTube page. Not only is this a fast and easy way to share content, but uploading content to your social media sites provides an additional backup of your content, as the content is stored both on your StorCenter ix2-dl and at your social media accounts.

How do I...

[make a Share an Active Folder](#)

[upload to Facebook](#)

[upload to Flickr](#)

[upload to YouTube](#)

Managing Your Content

You manage content on your Iomega StorCenter ix2-dl using the Content Viewer. The Content Viewer is a graphical file browser that lets you view and manage content in the Shares on your StorCenter ix2-dl .

The Content Viewer is divided into two panes. The left pane lists the Shares on the StorCenter ix2-dl and allows you to delete or add a Share. If you select a Share that contains pictures, you can start a slideshow of the pictures in that Share. The right pane lists the files and folders in a Share and allows you to delete content or upload a file to the Share.

To delete multiple files simultaneously, hold the Ctrl key on your keyboard and select each file, or drag your mouse over the filenames. Share content can be sorted, and you can switch between a list view and a thumbnail view of the files. When you are looking at content in a list view and you hover your mouse over an image, a thumbnail view of the image displays next to your mouse. If all the content cannot fit on one page, there are pagination controls that allow you to continue browsing the content.

Transferring Content to and from Your Iomega StorCenter ix2-dl with Copy Jobs

You can transfer content to and from your StorCenter ix2-dl using the Copy Jobs feature. Copy Jobs copies files from one storage device to another, either by a set schedule or immediately by the user. An example of a Copy Job scenario is if you keep pictures from your digital camera on a separate USB drive, but you also want to maintain a backup of these pictures on your StorCenter ix2-dl. Using Copy Jobs, you can create a task that copies your photos on the USB drive to a Share on your StorCenter ix2-dl, and you can set that task to a schedule so the images automatically copy at a specific time. This ensures that your photos are always safely backed up to your StorCenter ix2-dl in the event your USB device ever fails or is lost.

Note: While a Copy Job copies all data from one NAS device to another, it does not copy permissions or access rights from one NAS device to another.

All saved Copy Jobs display on the Copy Jobs page. From there, you can manually start and stop a Copy Job, view Copy Job information, modify a Copy Job, check its last run status, and, if applicable, view when the Copy Job is next scheduled to run.

When defining a Copy Job, you can copy data from or to any of the following:

- Any NAS device automatically discovered on the same subnet as your StorCenter ix2-dl
- Any NAS device that you manually add to the subnet using the Iomega Storage Manager
- Any external storage device, such as a USB device, connected to your StorCenter ix2-dl

When selecting what data to copy on the source storage device, you can choose a specific folder or all folders. You can also copy from a folder on an external storage device mounted to your StorCenter ix2-dl.

When selecting the destination device, you can copy files to the top-level folder on the destination device (the default option), or to an existing folder on this device, which adds the copied files into folders.

You can manually start or stop a Copy Job by clicking start or stop buttons on the Copy Jobs page. You can schedule a Copy Job to run automatically at a set day and time.

Copy Jobs Limitations


- Copy Jobs does not establish a continuous replication or mirroring relationship between the source and destination devices. You should not set up Copy Jobs for disaster recovery.
- Copy Jobs does not support transferring content from iSCSI drives.

Getting Content from a USB External Storage Device

You can transfer content to your Iomega StorCenter ix2-dl from external USB storage devices. The External Storage page displays a list of externally connected storage devices. You can connect supported external storage to your StorCenter ix2-dl using one of the provided USB ports. When you connect external storage to your StorCenter ix2-dl, that device content is accessible from the Shares page.

Safely removing external storage



Click  to safely remove the external storage. A confirmation dialog will display. Click Yes to remove the external storage. When the external storage has been removed from the **External Storage** table, it is safe to remove, and you may unplug it from the StorCenter ix2-dl. When the external storage is safely removed, its associated Share is removed as well.

iSCSI: Creating IP-Based Storage Area Networks (SAN)

iSCSI Overview

The iSCSI page allows you to create iSCSI drives on your Iomega StorCenter ix2-dl and allows the Iomega Storage Manager to communicate with those drives over a network. An iSCSI drive provides a single place for all your storage, which you can divide as needed to support all computers in your enterprise business. iSCSI is useful for transmitting large blocks of data over a network at a high speed.

Only one client computer can connect to an iSCSI drive at a time, so iSCSI drives are not for shared data. If your business is clustering clients, then a cluster can access iSCSI drives.

How do I ...


[add an iSCSI drive](#)

[manage an iSCSI drive](#)

[delete an iSCSI drive](#)

Adding iSCSI Drives

To add an iSCSI drive:

1. From the lomega StorCenter Console , click **iSCSI**.
2. When the iSCSI page opens, click  **Add an iSCSI drive**.
3. Enter a name for the iSCSI drive. How you name your iSCSI drive will depend on your lomega StorCenter meeting one of the following conditions:
 - If the **iSCSI/Volume Name** field displays by itself, enter a name for both. This field displays when your lomega device is new, has no existing volumes, and supports multiple volumes.
 - If the **Name** field displays by itself, enter a name for the iSCSI drive. This field displays when your lomega device is new or being upgraded and has only one volume.
 - If the options **Create a volume** and **Use an existing volume** display, select:
 - **Create a volume** to create a new volume for your iSCSI drive. This option displays when your lomega device is new, or if you are upgrading your lomega device and it has available space in its Storage Pools.
 - **Use an existing volume** to use an existing empty or shared volume. This option displays when you are upgrading your lomega device , have available space in your Storage Pools, and have already created multiple volumes. To use an existing empty volume, select **iSCSI/Volume Name** and enter a name for the iSCSI drive and volume. To use an existing shared volume, select **Shared Volume**, select the existing volume, and enter a name for the iSCSI drive.
4. Enter a size for the iSCSI drive. The size must be smaller than the free space available on your lomega device .
5. Click **Create** to create the iSCSI drive.

Enabling iSCSI Drives

1. Click **Settings** to begin configuring an iSCSI drive.
2. To set the discovery of the iSCSI drive using iSNS, check **Enable discovery with iSNS**.
3. Choose one of the following options:
 - **Use local iSNS server** — the device acts as an iSNS server for the iSCSI drives.
 - **Use external iSNS server** — you supply the IP address or host name of the external iSNS server for the iSCSI drives.
4. To enable the Challenge Handshake Authentication Protocol (CHAP), check **Enable two-way authentication (Mutual CHAP)**. With Mutual CHAP enabled, the client performs an additional check to confirm that it is using the correct device.
5. Enter a device secret (password) for Device Secret and then enter it again in the confirm box.
6. Click **Apply** to save your changes.

Connecting to iSCSI Drives

You can connect iSCSI drives on your lomega StorCenter to your computer using the lomega Storage Manager or the Microsoft software initiator. If you are using another type of software or hardware initiator, you must use the native tools provided with your initiator to connect your iSCSI drives.

Caution: Attempting to connect two clients (iSCSI initiators) to the same iSCSI drive at the same time may result in data corruption or drive damage. The Iomega StorCenter Console prevents you from connecting two clients (iSCSI initiators) to the same iSCSI drive at the same time, but if you connect to an iSCSI drive using native tools, you may encounter this issue. You can use the **Connected Clients** section to view a list of client computers connected to your Iomega StorCenter that are running iSCSI initiator software. On the iSCSI page, expand an iSCSI drive, then expand the Connected Clients section. If the iSCSI drive is in use, you will see a list of connected client computers running initiator software.

How do I ...

[manage iSCSI drives](#)


[delete iSCSI drives](#)

Managing iSCSI Drives

The page describes how to:

- [Change Access Permissions](#)

Changing Access Permissions

1. Expand **Access Permissions** to change user permissions on an iSCSI drive. When an iSCSI drive is first created, the user Everyone has read and write access to that iSCSI drive by default, which means that everyone on your network can read, write, and delete files to and from that iSCSI drive.
2. To limit access to this iSCSI drive to a specific set of users, click the  and choose one or more users from the pop-up window.
3. In the **Access Permissions** section, check **Read**, **Write**, or both to set access to the iSCSI drive for each user. If you create groups, you can also set access for groups in this way. To remove a user, leave both Read and Write unchecked for that user. If you grant read and write permissions to Everyone, the list of users is automatically cleared because all users (Everyone) have access to this iSCSI drive.
4. Click **Apply** to save your changes.

How do I...

[add an iSCSI drive](#)

[delete an iSCSI Drive](#)

Deleting iSCSI Drives

To delete an iSCSI drive:

1. From the Iomega StorCenter ix2-dI Console , click **iSCSI**.
2. Click the iSCSI name to expand the iSCSI drive.
3. In the iSCSI Information section, click **Delete** to delete the iSCSI drive.
4. Click **Yes** in the confirmation pop-up window.
5. If you do not wish to delete the iSCSI drive, click **Cancel** to return to the iSCSI page.

Storage Pool Management

Adding New Drives to Your Iomega StorCenter ix2-dl

StorCenter ix2-dl devices with multiple drives allow you to add new drives while the device is powered on.

Note: You can add one or both drives on a StorCenter ix2-dl . If you are using an Iomega StorCenter ix2, you can add only one drive at a time.


To install new hard drives in your StorCenter ix2-dl :

1. Mount the drive carrier containing the new drive in an available slot.
2. A confirmation dialog box displays as soon as the StorCenter ix2-dl detects the new hard drive. Click **Yes** to proceed.

Note: All data on the drive is deleted.

3. You are re-directed to the Iomega StorCenter ix2-dl Console .
4. Access the **Drive Management** page.
Your StorCenter ix2-dl displays the new hard drives in the bays they are mounted in.
5. To create a RAID Array, you must install a minimum of two hard drives. The same confirmation dialog box displays. Click **Yes** to proceed.

Note: You can create a Storage Pool using one hard drive if desired. You will not have any RAID protection options and can only select **None** from the RAID dropdown list while configuring your Storage Pool.

6. When all new drives are detected, click  **Add a Storage Pool**.
7. Complete the Storage Pool configuration options and select the desired drives on which to build the Storage Pool by checking the boxes next to them.
8. Allow a few minutes for the RAID array and Storage Pool to build. When complete, the Storage Pool status displays on the Drive Management page.

Backing up and Restoring Your Content

Backup and Restore Overview

Your Iomega StorCenter provides many ways to back up and restore content.

To back up content to and from your Iomega device , such as:

- Time Machine
- QuikProtect
- Copy Jobs

To back up and restore your Iomega device , there are:

- Copy Jobs
- Mozy Backup
- Amazon S3
- Iomega Personal Cloud features

Backup of Data through RAID Protection

The drives in your Iomega device are protected using a built-in, pre-configured technology that redundantly stores data across the drives. This technology, known as RAID (Redundant Array of Independent Disks), enables a series of drives to act together as a single storage system. For more information, refer to Understanding How Your Content Is Stored.

How do I ...

[back up Macs with Time Machine](#)

[back up with Copy Jobs](#)

[back up with Mozy Backup](#)

[back up with Amazon S3](#)

[back up with Iomega Personal Cloud](#)

Backing up to and Restoring from Your Device

Backing up Macs with Time Machine

Time Machine is a backup utility for Mac computers, and is included in Mac OSX 10.5 or later. It can back up and restore all files on Mac computers. Enable Time Machine on your Iomega StorCenter ix2-dl to allow Mac computers to back up to it. When you enable Time Machine, you choose a destination Share on the StorCenter ix2-dl where the backups are to be stored. Any Mac computers running the Iomega Storage Manager will automatically have backup folders created within that specified Share.

Enabling Time Machine Support

1. On the Time Machine page, click the switch on.
2. Click the **Settings** link and in the Time Machine settings dialog, select a destination Share from the Folder drop-down menu for the Time Machine backup folders.
3. Click **Apply**.

Turning on Time Machine also turns on [Apple file sharing](#).

Changing the Time Machine Destination Share

You can change the Time Machine backup destination Share by clicking **Settings** and selecting a different Share in the pop-up window. If you have been using Time Machine to back up your computer to the StorCenter ix2-dl, be sure to copy all your existing backup folders from your original destination Share to the new destination Share before changing the destination Share. If you do not copy your existing backups, they will be lost.

Manually Creating Backup Folders for Macs

You can create backup folders for any Macs that are not running Iomega Storage Manager by clicking




Add a Time Machine backup folder above the Time Machine table. In the dialog box that displays, enter the Apple Network Hostname and Ethernet ID of the Mac computer you are adding and click **Apply**. Be sure you are entering the exact hostname and ethernet ID from your Mac. Do not change capitalization, add spaces, or add any non-alphanumeric characters. The Mac is added to the Time Machine table, and a backup folder is created for it in the Time Machine Share.

Starting a Time Machine Backup

To start a backup, open Time Machine on your Mac, and select your StorCenter ix2-dl as the target.

Deleting Backup Shares for Macs

You can delete any Mac backup Shares. Click  next to the Mac in the Time Machine table to delete that Mac's folder.

Copy Jobs Overview

You can back up content to and from your Iomega StorCenter using the Copy Jobs feature. Copy Jobs copies files from one storage device to another, either by a set schedule or immediately by the user. An example of a Copy Job scenario is if you keep pictures from your digital camera on a separate USB drive, but you also want to maintain a backup of these pictures on your Iomega device. Using Copy Jobs, you can create a task that copies your photos on the USB drive to a Share on your Iomega device, and you can set that task to a schedule so the images automatically copy at a specific time. This ensures that your photos are always safely backed up to your Iomega device in the event your USB device ever fails or is lost.

For more information, refer to [Transferring Content to and from Your Iomega device](#).

How do I ...

[add a Copy Job](#)

[manage a Copy Job](#)

[modify a Copy Job](#)

[delete a Copy Job](#)

[restore files with Copy Jobs](#)

Backing up Your Device

Copy Jobs

Transferring Content to and from Your Iomega StorCenter ix2-dl with Copy Jobs

You can transfer content to and from your StorCenter ix2-dl using the Copy Jobs feature. Copy Jobs copies files from one storage device to another, either by a set schedule or immediately by the user. An example of a Copy Job scenario is if you keep pictures from your digital camera on a separate USB drive, but you also want to maintain a backup of these pictures on your StorCenter ix2-dl . Using Copy Jobs, you can create a task that copies your photos on the USB drive to a Share on your StorCenter ix2-dl , and you can set that task to a schedule so the images automatically copy at a specific time. This ensures that your photos are always safely backed up to your StorCenter ix2-dl in the event your USB device ever fails or is lost.

Note: While a Copy Job copies all data from one NAS device to another, it does not copy permissions or access rights from one NAS device to another.

All saved Copy Jobs display on the Copy Jobs page. From there, you can manually start and stop a Copy Job, view Copy Job information, modify a Copy Job, check its last run status, and, if applicable, view when the Copy Job is next scheduled to run.

When defining a Copy Job, you can copy data from or to any of the following:

- Any NAS device automatically discovered on the same subnet as your StorCenter ix2-dl
- Any NAS device that you manually add to the subnet using the Iomega Storage Manager
- Any external storage device, such as a USB device, connected to your StorCenter ix2-dl

When selecting what data to copy on the source storage device, you can choose a specific folder or all folders. You can also copy from a folder on an external storage device mounted to your StorCenter ix2-dl .

When selecting the destination device, you can copy files to the top-level folder on the destination device (the default option), or to an existing folder on this device, which adds the copied files into folders.

You can manually start or stop a Copy Job by clicking start or stop buttons on the Copy Jobs page. You can schedule a Copy Job to run automatically at a set day and time.

Copy Jobs Limitations


- Copy Jobs does not establish a continuous replication or mirroring relationship between the source and destination devices. You should not set up Copy Jobs for disaster recovery.
- Copy Jobs does not support transferring content from iSCSI drives.

Adding Copy Jobs


The page describes how to:


- [Add Copy Jobs](#)
- [Setting From Information](#)
- [Setting To Information](#)
- [Setting a Schedule](#)

Adding Copy Jobs



1. On the Copy Jobs page, click . A Copy Job is added to the top of the list and the Information section displays.
2. Enter a name for the Copy Job.
3. The **Overwrite Setting** determines what happens to files in the destination location if they have the same name as those in the source location. Select one of the following values from the Overwrite Setting drop-down menu:
 - **Overwrite and don't delete** – Files in the destination location are overwritten with files from the source location. Any files in the destination location that are not in the source location are preserved.
 - **Overwrite and delete** – Files in the destination location are overwritten with files from the source location. Any files in the destination location that are not in the source location are deleted. The destination location becomes an exact copy of the source location.
 - **Don't overwrite** – Only files in the source location that are not in the destination location are copied. No files are overwritten in the destination location.

From: Settings

1. In the **From:** section, click  to select a source location. This is the location of the files you want to copy. In the dialog, enter the Device Name or IP address in the text box, or select a device from the list. If a connected device is not listed, click the **Refresh** button.
2. Click **OK** to save your selection or click **Cancel**.
3. The **Protocol** drop-down menu displays if the source device is different from the device you are currently accessing; for example, it could be a separate NAS device on your network. From the **Protocol** drop-down menu, choose one of the following:
 - **Windows File Sharing** – The default value in the menu is Windows File Sharing and in most cases you should accept the default value. For more information, refer to [Windows File Sharing](#).
 - **rsync** – The rsync protocol can provide faster copying, but may not be available on all devices. If you are able to select the rsync protocol, and you want the rsync Copy Job to be secure, select the **Use secure rsync (SSH)** option. Enter the rsync username and password for the rsync server to or from which you are copying. The rsync username and password is set up on a different device than the device on which you are creating the Copy Job. For more information on creating an rsync user, refer to [rsync Server Settings](#).


4. Enter a valid username and password to provide access to folders on this NAS device, if applicable.
5. To select a specific folder, click  to select a source location for the **What to copy:** section. In the Copy dialog box, select all Shares or a folder, and select one of the following options for the Copy Job from the drop-down menu:
 - **The selected folder and its contents** – copies the selected folder and its contents. If the destination is a folder, a new folder will be created for each source folder. If the destination is Top Level, a new top-level folder is created on the destination device for each source folder.
 - **Only the contents of the selected folder** – copies the contents of the selected folder; not the folder itself. If the destination is a folder, the files and folders in the selected folder are copied directly to it (the source folder name is not copied). If the destination is Top Level, a new top-level folder is created on the destination device for each folder in the source folder.
6. By selecting Shares, you choose to copy All Shares, in which all files on the Iomega StorCenter ix2-dl StorCenter ix2-dl are copied. Any files not contained in a folder are not copied. If the destination is a folder, a new folder will be created for each source folder. If the destination is Top Level, a new top-level folder is created on the destination device for each source folder.
7. Click **OK** to save your selection or click **Cancel**.
8. Click **Apply** to save your changes.

To: Settings

1. In the To: section, click  to select a destination location. This is the location where you want your files copied. In the dialog, enter the Device Name or IP address in the text box. Or, from the drop-down menu, select a device in the list. If a connected device is not listed, click the **Refresh** button.
2. Click **OK** to save your selection or click **Cancel**.
3. The Protocol drop-down menu displays if the source device is different from the device you are currently accessing; for example, it could be a separate NAS device on your network. From the **Protocol** drop-down menu, choose one of the following:
 - **Windows File Sharing** - The default value in the menu is Windows File Sharing and in most cases you should accept the default value. For more information, refer to [Windows File Sharing](#).
 - **rsync** - The rsync protocol can provide faster copying but, may not be available on all devices. If you are able to select the rsync protocol, and you want the rsync Copy Job to be secure, select the **Use secure rsync (SSH)** option. Enter the rsync username and password for the rsync server you are copying from or to. The rsync username and password is set up on a different device than the device on which you are creating the Copy Job. For more information on creating an rsync user, refer to [rsync Server Settings](#).
4. Enter a valid username and password to provide access to folders on this NAS device, if applicable.
5. To select a specific folder, click  to select a destination location for the **Copy to here:** section. In the Copy to here dialog, select a Share or a folder from a Share to copy your files.

6. Click **OK** to save your selection or click **Cancel**.
7. Click **Apply** to save your changes.

Setting a Schedule

1. To set a schedule, expand the Schedule section.
2. In the Schedule section, select **Enable Schedule for Copy Job**.
3. Select the days you want the Copy Job to run, or select **All Days** to run the Copy Job every day.
4. Click  to select a start time. Click **Done** to save your time selection.
5. Click **Apply** to save your changes. The new Copy Job displays on the Copy Jobs page.

How do I ...

[manage a Copy Job](#)

[modify a Copy Job](#)

[delete a Copy Job](#)




[restore files with Copy Jobs](#)

Managing Copy Jobs

From the Copy Jobs page, you can add, start, stop, delete, or monitor Copy Jobs.

After you have added Copy Jobs, the Copy Jobs page displays a list of Copy Jobs. The information section includes the name of each Copy Job, date and time it last ran, and its next scheduled time.

From the Copy Jobs list, you can perform the following actions:

- 1 Click  to start a Copy Job.
- 2 Click  to stop a Copy Job.
- 3 Click  to [delete](#) a Copy Job.
- 4 Expand the **Copy Job Information** section to [modify](#) the Copy Job settings.
- 5 Click the **Schedule** section to view the Copy Jobs schedule.

How do I ...

[add a Copy Job](#)

[modify a Copy Job](#)

[delete a Copy Job](#)

[restore files with Copy Jobs](#)

Modifying Copy Jobs

1. In the list on the Copy Jobs page, find the Copy Job you want to modify, and click it to expand the **Information** section.
 2. Refer to [Adding a Copy Job](#) for information about revising the Copy Job fields.
-

How do I ...

[add a Copy Job](#)


[manage a Copy Job](#)

[delete a Copy Job](#)

[restore files with Copy Jobs](#)

Deleting Copy Jobs

1. In the list on the Copy Jobs page, find the Copy Job you want to delete.

2. Click  from the **Actions** column of the table to delete the Copy Job.

The Delete Copy Job pop-up window opens.

3. If you are sure that you want to delete the Copy Job, click **Yes**.

Note: If you do not wish to delete the Copy Job, click **Cancel** to return to the Copy Jobs page.

How do I ...

[add a Copy Job](#)

[manage a Copy Job](#)

[modify a Copy Job](#)

[restore files with Copy Jobs](#)

Restoring Files with Copy Jobs

To restore files with Copy Jobs, create a new Copy Job that reverses the back-up Copy Job. Modify the From and To settings to copy files from the backup location to the original source location, specify what to restore, set overwrite settings, and choose the protocol for the Copy Job.

Refer to [Add A Copy Job](#) for detailed information on Copy Job settings.

How do I ...

[add a Copy Job](#)

[manage a Copy Job](#)

[modify a Copy Job](#)

[delete a Copy Job](#)

Mozy Backup

The Mozy online backup service allows you to create a Mozy account, connect your Iomega StorCenter ix2-dl to the account, and back up Shares and folders to the Mozy cloud service.


Enabling Mozy Account Information

1. On the Mozy Backup page, click the switch on.

Note: If you do not have a Mozy account, click the link to open an account.

2. Enter a valid email address, password, license key, and country for your Mozy account.
3. To upgrade your Mozy account, click the link.
4. Click **Apply** to save your changes.

Selecting Folders to Back Up

1. Expand the **Backup** section and select the Shares and folders to back up in the tree. The tree provides a way to select a Share and all its folders, or just some of the folders under a Share.
2. Click **Apply** to save your changes.
3. To create a scheduled backup, click **Backup schedule settings**.
4. In the Mozy Backup Settings dialog box, select one of the following:
 - **Automatic Backup** – to generate an automatic backup anytime you add a new file or change an existing file to your selected Shares or folders.
 - **Scheduled Backup** – to set up a scheduled backup.
5. If you are creating a scheduled backup, select the days you want the backup to run.
6. Enter the start or stop times for the backup, or click  to select the times.
7. To prevent performance degradation on your StorCenter ix2-dl, select a speed limit for the backup.
8. To schedule the time that the backup will run at the selected speed, enter start and stop times.
9. Click **Apply** to save your changes.
10. Click **Apply** to save the selected Shares and folders to back up.

After a backup has completed, click **View log** to see which files have been successfully backed up by Mozy.

How do I ...

[restore files with Mozy](#)

Restoring Folders with Mozy Backup


To restore folders and files with Mozy Backup:

1. Click the link to restore any files and folders you back up to your Mozy account.
2. Select the desired backup from the **Backup Date**: drop-down menu, either the latest backup or a previous one.

The file browser provides a way to select a Share and all its folders, or just some of the folders under a Share.

3. Click **Apply** to save your changes.

The Restore section displays a table with the status of a restore, either one in progress or

one that has failed. To delete the restore task, click  and confirm the deletion. When the restore finishes, the table status clears.

How do I ...

[back up files with Mozy Backup](#)

Amazon S3

The Amazon S3 online storage service allows you to back up your Iomega StorCenter ix2-dl to the cloud.

Enabling the Amazon S3 Feature

1. On the Amazon S3 page, click the switch on.

Note: If you do not have an Amazon S3 account, click the link to create an account.

2. Enter a valid access key, secret key, and bucket name from your Amazon S3 account information.
You can create a bucket at account setup, or you can enter a new bucket for your StorCenter ix2-dl . Your content lives in this bucket on your Amazon S3 account.
3. Select an existing Share on your StorCenter ix2-dl in which to copy files that are then backed up to Amazon S3.
4. Click **Apply** to save your changes.

Backing up Files to the Amazon S3 Cloud

After you copy files to the selected Share on your StorCenter ix2-dl , the files are automatically backed up to the Amazon S3 cloud service. File uploads are limited to 5 GB in size. If you delete files from the selected Share on your StorCenter ix2-dl , they are not automatically deleted from the cloud service. You can manually delete those files from the cloud service by clicking a command on the Amazon S3 page.

How do I ...

restore files with Amazon S3

Restoring Files with Amazon S3

When you want to restore files from the Amazon S3 cloud service to your Iomega StorCenter ix2-dl , you can choose to restore all files or select individual files to restore.

How do I ...

[back up files with Amazon S3](#)

Backing up with Iomega Personal Cloud

You can back up content on your Iomega StorCenter by creating a Copy Job from the Iomega Personal Cloud on it to another Iomega device that is a member of the cloud.

Refer to Iomega Personal Cloud help for additional information.

How do I ...

[create an Iomega Personal Cloud](#)

[create Copy Jobs with Iomega Personal Cloud](#)

Restoring with Personal Cloud

You can restore content on your Iomega StorCenter by creating a Copy Job from the Iomega Personal Cloud on it to another Iomega StorCenter that is a member of the Personal Cloud.

Refer to Iomega Personal Cloud help for additional information.

How do I ...

[create an Iomega Personal Cloud](#)

[create Copy Jobs with Iomega Personal Cloud](#)

Securing Your Device and Contents

What Is Security and Do I Need It?

Security is an optional feature you can enable on your Iomega StorCenter ix2-dl to secure Shares, create users, and allow some features to be enabled. When you create users, you limit access to your StorCenter ix2-dl to specific people, and when you secure Shares, you limit data access to specific users. Security adds an extra layer of protection to your StorCenter ix2-dl beyond whatever form of security you have on your local network. Without security, all data on your StorCenter ix2-dl can be accessed by anyone on your local network.

To secure your StorCenter ix2-dl :

- First [enable security](#) and create an administrator user.
- Create [users](#). Create [groups](#) .
- Secure any existing or new Shares.
- Secure any existing or new iSCSI drives.

How do I...

[enable security](#)

[add users](#)

[add groups](#)

[secure Shares](#)

Enabling Security and Creating an Administrator User

With security turned on, only administrator users can view or change settings on the StorCenter ix2-dl, including creating or deleting users and Shares. When you create users, you limit access to your StorCenter ix2-dl to specific people, and when you secure Shares, you limit data access to specific users.

1. On the Security page, click the switch on.
2. When you turn security on, you will be asked to create an administrator user. Provide a username and password, and then confirm your password.
3. Encryption is always available when you access your StorCenter ix2-dl using https. By setting local encryption, you enforce encryption on your local network. By setting remote encryption, you enforce encryption outside your local network, such as through the internet. Choices for both encryption types are Not required, Passwords only (passwords are encrypted through https), and Always (encryption is always enforced). Always encrypting communication is safest, but can impact performance.

Note: When security is turned on, browser communications with the StorCenter ix2-dl are encrypted. Therefore, each computer that attempts to access the StorCenter ix2-dl may encounter a security warning, which can be safely ignored. In addition, you may be asked to accept a signed certificate for the StorCenter ix2-dl, which you should accept. If you change the device name at a later date, these warnings may appear again.

StorCenter ix2-dl administrators do not have access to all Shares by default. Access rights to Shares must be granted explicitly to administrators, as with other users.

4. If you have your own security certificate, you can load it by selecting **Use an imported certificate** and browsing to the certificate to load it.
5. Click **Apply** to save your changes.
6. [Click here](#) to learn how to create users.
7. [Click here](#) to learn how to secure any existing or new Shares.

Disabling Security

Disabling security will cause all defined users to be deleted.

Note: If you are using other features on your StorCenter ix2-dl that require security, you cannot disable security until those features are also disabled.

1. On the Security page, click the switch off.
2. Disabling security will cause all defined users and groups to be deleted. Check the box to disable security.
3. Click **Apply** to save your changes.

Security is disabled.

How do I...

[create secured Shares](#)

[add users](#)

Limiting Access to Your Content by Creating Users

When you create users, you are selecting the specific people that have access to your Iomega StorCenter . You can secure Shares and specify which users can read and write to the secured Shares. You can also create additional administrator users who can manage the Iomega device through the Iomega StorCenter Console . Administrator users can change various settings on the Iomega device , including adding and deleting Shares. If you create groups, you can also limit access to your Iomega device by group so you don't have to specify access for each individual user.

How do I ...

[add users](#)

[add groups](#)

Users

Users Overview

When security is enabled, the Users page displays all users on the Iomega StorCenter ix2-dl and enables administrators to add and modify users.

Non-administrator users can be added to limit access to Share content. Additional administrator users can be added allow specific users to configure the StorCenter ix2-dl . The table displays the Usernames and Descriptive Name of each user. Click in a row of the table to view or modify details about a user.

How do I...

[add users](#)


[manage users](#)

[delete users](#)

[create Shares for users](#)

Adding Users

To add a user:

1. Navigate to the **Users** page.
2. Before you can create or modify users, you must have [security enabled](#) on your lomega StorCenter lomega device . If security is already enabled, you are ready to add users. If not, a pop-up window appears for enabling security and create an administrator user to manage your secured lomega device .
3. To add a new user, click  **Add a user**.
4. Enter the following information:
 - **Username** – enter the username of the user to be created. This is the username for logging into the lomega device . There is a maximum of 32 characters, and spaces are not allowed. The following are not valid usernames: root, daemon, bin, sys, sync, mail, proxy, www-data, backup, operator, sshd, postfix, nobody, unuser, guest, and rsync.
 - **Descriptive Name** – add a descriptive name to identify the user. For example, if you created a user with a Username of jsmith, you may want to add the Descriptive Name Joe Smith.
 - **Password** – create a password for the user. The password should be between 8 and 12 characters, and spaces are not allowed.
 - **Confirm Password** – confirm the password. If the text in this field does not match the text in the Password field, an error will be returned.
 - **Quota Size** – set a quota size by entering a value in gigabytes. This limits the amount of storage space this user can have. To have no quota, leave this field blank.
 - **Administrator** – check this box to allow this user to manage the lomega device .

Note: An administrator does not have default access to all Shares. Access to Shares must be granted explicitly to all users, including administrators.

 - **Add a secured Share for this user** – check this box to create a secured Share for this user. This Share will have the new user's name, and allows access only to that user.
 - **Send a Personal Cloud invitation** – click this link to invite a user to join your Personal Cloud on the lomega device . This opens the Send a Personal Cloud Invitation dialog box where you create an invitation by entering a user's email address along with any additional comments. A user then receives the invitation, which contains the Personal Cloud name and username and password. A user enters that information from lomega Storage Manager . For more information on this, refer to the online help with lomega Storage Manager . You see this option only if a [Personal Cloud has been created](#) on the lomega device .
 - **Allow this user to add trusted devices to my Personal Cloud** – check this box to allow a user to [join a trusted device](#) to a Personal Cloud. A trusted device is a machine, either a computer or another lomega device , that belongs to an added user. Only trusted devices that belong to users that have been added to the lomega device can join the lomega Personal Cloud . This option displays only if a [Personal Cloud has been created](#) on the lomega device .
5. Click **Create**.

Managing Users

The page describes how to:

- [Change User Information](#)
- [Change Access Permissions](#)
- [Set Quotas](#)

Changing User Information

1. Modify the following information:

- **Username** – enter the username of the user to be created. This will be the username provided when logging into the lomega StorCenter ix2-dl . There is a maximum of 32 characters, and spaces are not allowed. The following are not valid usernames: root, daemon, bin, sys, sync, mail, proxy, www-data, backup, operator, sshd, postfix, nobody, unuser, guest, and rsync.
 - **Descriptive Name** – add a descriptive name to identify the user. For example, if you created a user with a Username of jsmith, you may want to add the Descriptive Name Joe Smith.
 - **Password** – create a password for the user. The password should be between 8 and 12 characters, and spaces are not allowed.
 - **Confirm Password** – confirm the password. If the text in this field does not match the text in the Password field, an error will be returned.
 - **Send a Personal Cloud invitation** – click this link to invite a user to join your Personal Cloud on the StorCenter ix2-dl . This opens the Send a Personal Cloud Invitation dialog box where you create an invitation by entering a user's email address along with any additional comments. A user then receives the invitation, which contains the Personal Cloud name and username and password. A user enters that information from lomega Storage Manager . For more information on this, refer to the online help with lomega Storage Manager . You see this option only if a [Personal Cloud has been created](#) on the StorCenter ix2-dl .
 - **Allow this user to add trusted devices to my Personal Cloud** – check this box to allow a user to [join a trusted device](#) to a Personal Cloud. A trusted device is a machine, either a computer or another StorCenter ix2-dl , that belongs to an added user. Only trusted devices that belong to users that have been added to the StorCenter ix2-dl can join the lomega Personal Cloud . You see this option only if a [Personal Cloud has been created](#) on the StorCenter ix2-dl .
 - **Quota Size** – set a quota size by entering a value in gigabytes. To have no quota, leave this field blank.
 - **Administrator** – check this box if you would like to allow this user to manage the StorCenter ix2-dl .
-
- **Note:** An administrator does not inherently have access to all Shares. Access to Shares must be granted explicitly to administrators, as with other users.
-

2. Click **Apply**.


Changing Access Permissions

1. Expand **Access Permissions** to change Share access permissions for the selected user.
2. To give this user access to a specific set of Shares, click **Add access permissions**.

3. In the Add Access Permissions pop-up window, select which Shares this user can access, and click **Apply**.
4. Uncheck Read or both Read and Write to limit or deny access permission to each Share for this user.
5. Click **Apply** to save your changes. When both Read and Write are unchecked, the Share is removed from the list.

Setting Quotas

You can limit the amount of space allocated to one or more users by applying quotas.

1. Click  **Quota Settings** to enable quotas, and set a default quota for each user.
2. In the **Quota Settings** pop-up window, check **Enable quotas** to turn on quotas for each user.
3. If desired, enter a **Default Quota**. This quota applies to new users only.
4. Check **Set default quota for all users** to apply the default quota to all users.
5. Click **Apply** to save your changes.
6. To set individual user quotas, expand the **Information** section for a user and enter a value in **Quota size**. If you leave the box blank, there is no quota for that user.
7. Click **Apply** to save your changes.

Deleting Users

To delete a user:

1. From the Iomega StorCenter ix2-dl Console , click **Users**.
2. To delete an existing user, click the username to expand the user.
3. In the User Information section, click **Delete**.
4. In the **Delete User** pop-up window, click **Yes**.
5. The user is removed from the user list.

Groups

Groups Overview

Groups consist of one or more users, and administrators can grant each group rights to Shares on the lomega StorCenter ix2-dl . Users can belong to more than one group. The Groups page enables administrators to create one or more groups, and grant each group rights to Shares on the StorCenter ix2-dl . Security must be enabled before you can create groups.

Note: Refer to the [Security](#) page to enable security permissions and create an administrator account, if you have not done so already.

By default, there are no groups defined. Once an administrator defines one or more groups, the Groups functionality is dynamically available when creating, modifying, and viewing users, Shares, and groups.

How Access Rights Are Granted Using Groups in Workgroup Mode

When groups are defined in Workgroup mode, a user's access rights are the most rights granted to the user and all groups to which the user belongs. For example, assume 3 Shares exist (SF1, SF2, and SF3), two users (UserA and UserB), and three groups (Group1, Group2, Group3). When created, UserA was not granted access rights to any Share, and UserB was granted Read rights to SF3. Group1 has Read/Write rights to SF1, Group2 has Read/Write rights to SF2, and Group3 has Read/Write rights to SF3. If UserA is added to Group1, UserB is added to Group2, and Group1 is added to Group3, the table below shows the resulting access rights for each user and group defined:

Name	Member of Group	Access Rights
UserA	Group1, Group3	SF1 - Read/Write SF3 - Read/Write
UserB	Group2	SF2 - Read/Write SF3 - Read
Group1	Group3	SF1 - Read/Write SF3 - Read/Write
Group2	none	SF2 - Read/Write
Group3	none	SF3 - Read/Write



How do I...

[add new groups](#)

[add users](#)

[delete users](#)

Adding Groups


1. On the Groups page, click  **Add a group**. The Information section opens.
2. From the Information section, give the new group a name.
3. To add users to the group, click  **Add users**. Select a user or users to include in the group. Select the checkbox in the title bar to add all listed users.
4. Click **Apply** to save your changes.

Managing Groups



The page describes how to:

- [Remove a User from a Group](#)
- [Change Access Permissions](#)

Removing a User from the Group

1. Open a group to display users belonging to it.
2. To remove a user from the group, click the  next to that user. When the **Remove user** pop-up window appears, click **Yes** to remove the user.

Changing Access Permissions

1. To refresh the list of users, click  above the table.
2. Expand **Access Permissions** to change group permissions to a secured Share. If iSCSI is enabled, you can also change group permissions to secured iSCSI drives .
3. To add permissions to a Share, click  **Add access permissions**.
4. From the **Add Access Permissions** pop-up window, select a Share or Shares for the group to access. If iSCSI is enabled, select iSCSI drives for the group to access. Select the checkbox in the title bar to select all the Shares listed. If iSCSI is enabled, select the checkbox in the title bar to also select all the iSCSI drives listed.
5. Click **Apply** to save your changes.
6. In the table listing the Shares, check **Read** or **Write** for each Share. If iSCSI is enabled, check **Read** or **Write** for each iSCSI drive. The group can have full access by checking both **Read** and **Write**. To grant only read access, check only **Read**.

Note: A group must have read access at a minimum. A group cannot have only write access.

7. Uncheck **Read** to remove all access to a Share and remove the Share from the table. If iSCSI is enabled, uncheck **Read** to remove all access to an iSCSI drive and remove the iSCSI drive from the table.
8. Click **Apply** to save your changes.
9. If NFS is enabled, the **GID** field is visible. The GID value must be the same on both the Linux client and the Iomega StorCenter ix2-dl for the client to access files. To modify the GID, type a new GID value.

Deleting Groups

To delete a group:

1. From the lomega StorCenter ix2-dl Console , click **Groups**.
2. To delete an existing group, click to expand the group.
3. In the Information section, click **Delete** to delete the group.
4. In the **Delete Group** confirmation pop-up window, click **Yes**.
5. If you do not wish to delete the group, click **Cancel** to return to the Groups page.

Using Active Directory Domain to Manage Users and Groups

Active Directory Users and Groups Overview

On the Users and Groups page, administrator users can import users and groups from an Active Directory server and grant them access rights to Shares on the Iomega StorCenter ix2-dl . The Users and Groups page is visible when you enable Active Directory on the StorCenter ix2-dl . For more information on enabling Active Directory on the StorCenter ix2-dl , refer to [Configuring Your StorCenter ix2-dl to Use AD Domain](#). For information on creating an administrator user, refer to [Enabling Security and Creating an Administrator User](#).

How do I...

[enable security](#)

[change Active Directory settings](#)

[manage Active Directory users and groups](#)


[delete users and groups from Active Directory](#)

Managing Users and Groups with Active Directory

The page describes how to:

- [Import Users and Groups from Active Directory](#)
- [Synchronize with the Active Directory Controller](#)
- [Change Access Permissions](#)
- [Set Quotas](#)

Importing Users and Groups from Active Directory


1. Click  **Import Users and Groups from Active Directory**.
2. The pop-up window for **Import Users and Groups from Active Directory** is searchable, and you can sort by name, descriptive name, or type. You can filter the list of users and groups by selecting a specific user or group from the domain tree.
3. Select the checkbox next to a user or group to import that user or group to your lomega StorCenter ix2-dl from your Active Directory domain. Select the checkbox in the title bar to select all the users and groups in your Active Directory domain.
4. Click **Apply** to save your changes.

Synchronizing with the Active Directory Controller

You can poll the Active Directory controller at any time to check for new users and groups on the controller, so you can add them to your StorCenter ix2-dl . This keeps your StorCenter ix2-dl up to date with any group changes on the controller and indicates if any users on the controller were deleted or promoted.

Click  **Synchronize with the Active Directory Controller**.


Changing Access Permissions

1. Expand **Access Permissions** to change user or group permissions to a secured Share. If iSCSI is enabled, you can also change user and group permissions to secured iSCSI drives.
2. To add permissions to a Share, click  **Add access permissions**.
3. From the **Add Access Permissions** pop-up window, select a Share or Shares for the user or group to access. If iSCSI is enabled, select iSCSI drives for the user or group to access. Select the checkbox in the title bar to select all the Shares listed. If iSCSI is enabled, select the checkbox in the title bar to also select all the iSCSI drives listed.
4. Click **Apply** to save your changes.
5. In the table listing the Shares, check **Read** or **Write** for each Share. If iSCSI is enabled, check **Read** or **Write** for each iSCSI drive. A user or group can have full access by checking both **Read** and **Write**. To grant only read access, check only **Read**.

Note: A user or group must have read access at a minimum. A user or group cannot have only write access.

6. Uncheck **Read** to remove all access to a Share and remove the Share from the table. If iSCSI is enabled, uncheck **Read** to remove all access to an iSCSI drive and remove the iSCSI drive from the table.
7. Click **Apply** to save your changes.
8. If NFS is enabled, the GID field is visible. The GID value must be the same on both the Linux client and the StorCenter ix2-dl for the client to access files. To modify the GID, type a new GID value.

Setting Quotas

1. Click  **Quota settings** to enable quotas and set a default quota. Quotas are only set for individual users, and not groups.
2. In the **Quota Settings** dialog, click **Enable quotas** to turn on quotas for each user. Quotas can be set for each user individually or set as a default value.
3. Enter a **Default Quota** in gigabytes. When you set a default quota, this becomes the quota size for all new users.
4. Check **Set default quota for all users** to globally set the same quota size to all users. You may overwrite this default value for individual users by setting their quota size separately in the user's Information section.
5. Click **Apply** to save your changes.

Deleting Active Directory Users and Groups

To delete a user or a group:

1. From the Iomega StorCenter ix2-dl Console , click **Users and Groups**.
2. To delete an existing user or group, click to expand that user or group.
3. In the Information section, click **Delete**. Deleting a user or group does not delete any Shares to which the user or group has access. Click the checkbox if you want to **Delete all Shares that only this user can access**.
4. In the confirmation pop-up window, click **Yes**.
5. If you do not wish to delete a user or group, click **No** to return to the Groups page.

Personal Cloud: Accessing Your Device From Anywhere in the World

What Is an Iomega Personal Cloud ?

An Iomega Personal Cloud turns an Iomega StorCenter ix2-dl into a hub for sharing files and backing up data among computers anywhere in the world. A Personal Cloud can exist on your Iomega StorCenter ix2-dl, or on another Iomega network device. When you create a Personal Cloud, you gain access to your StorCenter ix2-dl from anywhere on the internet. You can also share with friends and family by inviting users to join your Personal Cloud. You manage Personal Cloud users the same way you manage other users on your StorCenter ix2-dl, so you control the storage and content they can access through the Personal Cloud. Trusted devices can be added to your Personal Cloud to connect them through the internet as if they are on a common home network with your StorCenter ix2-dl. People who join your Personal Cloud can access data, perform Copy Job operations, use your StorCenter ix2-dl as a QuikProtect remote target, stream media from your StorCenter ix2-dl over the internet, and use remote desktop to access computers on the local network for your StorCenter ix2-dl. If you allow a user to join their trusted devices to the Cloud, those devices become part of the Cloud and can be accessed by other users on the Cloud.

Iomega Personal Cloud Key Terms

The following are a few key terms to help get you started with a Personal Cloud:

- **Iomega Personal Cloud** — This is a setting configured on your Iomega StorCenter ix2-dl Console that allows you to securely share storage and media capabilities with computers around the world.
- **Web Access** — You can use Personal Cloud information to access your StorCenter ix2-dl from the web. Enter myCloudName.Myiomegacloud.com in a web browser, and when prompted, enter a valid username and password for your StorCenter ix2-dl. You can also use the Iomega Link, which is an application that runs on mobile devices, by entering the Personal Cloud name and then a valid username and password. For more information on the Iomega Link, refer to its documentation.
- **My Personal Cloud** — When you are the administrator of an StorCenter ix2-dl, you can create a Personal Cloud through the Iomega StorCenter ix2-dl Console and then invite people to join it. You create and manage the Personal Cloud on your Iomega StorCenter ix2-dl Console through the **My Personal Cloud** configuration option. The Personal Cloud that you administer is called My Personal Cloud.
- **Other Personal Cloud** — If you want to have your StorCenter ix2-dl join that Personal Cloud instead of administering your own, select the option for **Other Personal Cloud**. Enter the Personal Cloud name, username and password you received when you were invited to join your StorCenter ix2-dl as a Trusted Device on the other Personal Cloud.
- **Joining an Iomega Personal Cloud as a Trusted Device** — To connect your computer or your StorCenter ix2-dl as a trusted device to a Personal Cloud, you use the username and password given to you for that Personal Cloud. The person managing the Personal Cloud has to create you as a user on the device hosting the Personal Cloud and give you permission to add trusted devices. You can connect your StorCenter ix2-dl to only one Personal Cloud at any given time, so you must select between either My Personal Cloud or Other Personal Cloud.

An administrator should complete the following tasks to set up or join a Personal Cloud:

- [create a Personal Cloud](#)
- [invite people to a Personal Cloud](#)

- [join a trusted device to a Personal Cloud](#)

Is My Content Secure?

Your content is always secure using an Iomega Personal Cloud . If you create a Personal Cloud with security disabled, you are required to enter a password when accessing your Iomega device remotely. [Enabling security](#) allows you to share your Iomega device with the people you choose. For example, you have photos of your new baby you want to share with your sister, your brother, and your sister-in-law. To share your baby photos with these family members, create a Personal Cloud, and then invite your sister, your brother, and your sister-in-law to join your Personal Cloud. Your Iomega StorCenter provides an easy way to send email invitations and instructions to the people you select as Personal Cloud users. In this way, your content is never exposed to the public, and remains private. It is visible only to the individuals you invite to be Personal Cloud users. Content of the Personal Cloud is determined by you as the Personal Cloud owner. Refer to the help topic links below for more information on Personal Cloud.

Note that people added to your Personal Cloud as users are not required to own or have access to an Iomega device . The process of adding someone as a Personal Cloud user grants them access to your Personal Cloud from any computer.

How do I ...

[create an Iomega Personal Cloud](#)

[configure a router for port forwarding](#)

[create a Personal Cloud](#)

[invite people to a Personal Cloud](#)

[join a trusted device to a Personal Cloud](#)

[enable security on Iomega device](#)

Iomega Personal Cloud Setup Overview

You can create an Iomega Personal Cloud in one of two ways:

- Follow the Iomega Personal Cloud setup through Iomega Setup
- Create the Iomega Personal Cloud through the Iomega StorCenter Console

Creating an Iomega Personal Cloud starts with providing a name for your Personal Cloud and an email address associated with it. After creating the Personal Cloud, you can use the Personal Cloud Quick Setup wizard to perform common tasks associated with the Iomega Personal Cloud : adding Shares, inviting people to join the Personal Cloud, and setting up Copy Jobs through the Personal Cloud.

How do I ...

[enable security on my Iomega device](#)

[create an Iomega Personal Cloud](#)

[configure a Personal Cloud](#)

[invite people onto your Personal Cloud](#)

[join a trusted device to a Personal Cloud](#)

[use Copy Jobs with a Personal Cloud](#)

Creating an Iomega Personal Cloud

Before you can work with your Iomega Personal Cloud, you first create a Personal Cloud and configure the settings.

After your Personal Cloud is ready and connected to the internet as indicated by the status images, you can invite people to join your Personal Cloud. When you invite people to join your Personal Cloud, you add them as users on your Iomega StorCenter . The invited users receive an email invitation that includes the username and password they must provide when connecting to the Personal Cloud from the Iomega Storage Manager on their computer.

If you have content on your Iomega device that you do not want to share with members of your Personal Cloud, you should put that content in secured Shares that are not accessible to anyone invited to your Personal Cloud.

Note: This procedure assumes you did not create a Personal Cloud using the initial [Iomega Setup portal](#). If you have already created a Personal Cloud, you do not have to follow this procedure.

1. On the Iomega Personal Cloud page, expand the **Configure** section.
2. Click the **My Personal Cloud** button to open the portal that lets you create your Personal Cloud.

After you click the My Personal Cloud button, a new website containing the portal opens. You create a Personal Cloud on this website. After you create the Personal Cloud, you return to the Iomega StorCenter Console.

3. If your Iomega device is not secured, you are prompted to create a remote access password. This is a password that anyone not on your local network must enter to access your device.

After completing these steps, the Personal Cloud Quick Setup Wizard opens, so you can [create Shares](#), [invite users](#), or configure [Copy Jobs](#). You can use the Quick Setup Wizard or close it and begin using your Personal Cloud.

How do I...


[invite people to a Personal Cloud](#)

[join a trusted device to a Personal Cloud](#)

[enable security on Iomega device](#)

Configuring Router Port Forwarding for Personal Cloud

In most cases, your Iomega StorCenter attempts to automatically configure your router. However, if it cannot, a message displays that your router is not configured for port forwarding, and you must manually configure your router to forward a specific port to your Iomega device. Most routers refer to this as port forwarding, application access, or virtual server. It is recommended that you refer to your router's documentation for setting these values. When you set up port forwarding, you are allowing data to travel through your Personal Cloud between your Iomega device and trusted devices.

When you have selected a port value to forward for Personal Cloud, click  **Settings** on the Personal Cloud page, and enter your selected port number in the Personal Cloud settings dialog box. If you have more than one Personal Cloud, you can enter a range of port values for your Personal Clouds. The range of port values is 50500-50599. You must also port forward port 443 to enable https access to your Iomega device.

Router Port Forwarding

Some routers have a UPnP option. If you have a UPnP router, enabling this option allows the Iomega device software to automatically configure the correct forwarding ports. Otherwise, you must perform additional steps by manually enabling port forwarding on your home network router. Port forwarding allows invited users to connect remote computers or other Iomega device devices outside of your local area network (LAN) as trusted devices to the Personal Cloud on your network.

Note: Port forwarding must be configured for both the network router on which the Personal Cloud is configured, and any remote network from which trusted devices are accessing the Personal Cloud.

The following steps are generic router settings. If you have never logged into your router before, you must consult the manufacturer's documentation to find specific details such as default IP address, default administrator account, and password.

1. Log in to your router by entering its IP address in the browser's URL field from your computer. If prompted, enter administrator account name and password.
2. Navigate to the Port Forwarding configuration page. This is often related to Port Mapping, Application, Virtual Server, or Gaming configuration options.
3. Type in the desired application or service name. This is typically a blank or drop-down field where you can type or choose a user-specified application or service name for the port you are forwarding. Create a new entry with a value like "Iomega Personal Cloud" in this field.
4. Enter a port number for the Personal Cloud service in the range 50500-50599 in both the port start and port end fields. Port number 50500 is the default. It should not be necessary to change this value, but if you do, choose the next available port; for example, 50501. If you decide to choose a port in the higher range, note that the Media Server uses the same range of ports, numbering backwards from 50599.
5. Repeat the previous step, using port 443 to enable https communication with your Iomega device.
6. Enter the IP address of your Iomega device which contains the Personal Cloud. The IP address displays on the System Status page when you log into the device's web interface.
7. Save the changed settings.
8. Reboot the router if required.

How do I ...

[create an Iomega Personal Cloud](#)

Configuring Your Iomega Personal Cloud

As an Iomega Personal Cloud administrator, you can manage various settings on your Personal Cloud to ensure that it functions as efficiently as possible. Settings include specifying an email address when sending invitations. When data is traveling through the Personal Cloud, you can control the security of that information by specifying a Secure Communication level. Note that data stored on your StorCenter ix2-dl through the Personal Cloud is not encrypted, and using encryption can slow down communications.

Enabling Internet Access to the StorCenter ix2-dl

You can grant internet users, including Iomega Link users, secure access to the web interface and unrestricted access to media content on your StorCenter ix2-dl . Iomega Link is an application that runs on mobile devices, and allows access to content on your StorCenter ix2-dl . Before enabling secure access, you must first [enable security](#) on your StorCenter ix2-dl and [create users](#). After enabling secure access, any internet users can access your StorCenter ix2-dl , and view any public content. Secure content is restricted to internet users who have valid usernames and passwords for the StorCenter ix2-dl . When you enable unrestricted media content access, your media files become available to all internet users.

Changing Personal Cloud Settings

1. In the Configure section of the Personal Cloud page, click **Settings**.
2. In the Personal Cloud Settings dialog box, configure the following:
 - **Administration Email Address** – This is the sender email address used on the email invitations.
 - **Port Number** – Your router forwards this specific port for your Personal Cloud. This value is automatically filled in, and you do not have to change it, unless you have more than one Personal Cloud on your network. Refer to [Configuring Router Port Forwarding for Personal Cloud](#) for more information.
 - **Secure Communication** – This setting controls the security of information traveling through the Personal Cloud.

 - **Note:** You can also specify a Secure Communication level setting with Iomega Storage Manager . The Secure Communication setting for the Iomega StorCenter ix2-dl Console sets the minimum value. You cannot specify a setting lower than this value using Iomega Storage Manager . For information on using Iomega Storage Manager , refer to its online help.
3. Click **Apply** to save your changes.

How do I...

- [create a Personal Cloud](#)
- [configure a router for port forwarding](#)
- [invite people onto your Personal Cloud](#)
- [join a trusted device to a Personal Cloud](#)
- [manage trusted devices on a Personal Cloud](#)
- [disable or delete my Personal Cloud](#)
- [enable security on StorCenter ix2-dl](#)
- [enable the Home Page](#)

Inviting People onto Your Iomega Personal Cloud

When you invite people to join your Iomega Personal Cloud, you are actually selecting from existing users on your Iomega device, or adding people as users on your Iomega device. In addition, you are optionally allowing them to add their computers or [Iomega storage devices as trusted devices](#) on your Personal Cloud. Computers are added as trusted devices through Iomega Storage Manager. Refer to its online help for more information.

1. From either the Personal Cloud Quick Setup dialog box or the Iomega Personal Cloud page, click **Invite Users**.

Note: You can also send an invitation to join a Personal Cloud when you are adding users. Refer to [Adding Users](#) for more information.

2. In the Invite Users dialog box, select the name of an existing user or click **Create New User** to [add a new user](#). If [security has not been enabled](#), you are prompted to enable security and create an administrator user.
3. If the email address field is not already completed, enter an email address for the user.
4. Click **Apply** to send the invitation.

How do I ...

[create an Iomega Personal Cloud](#)

[add users to my Iomega device](#)

Joining a Trusted Device to an Iomega Personal Cloud

You can join your Iomega StorCenter ix2-dl to the Personal Cloud as a trusted device if you have been given permission by the person administering the Personal Cloud.

Note: You cannot join your trusted device to a Personal Cloud if you have not been added as a user on the Personal Cloud.

1. On the Personal Cloud page, select the **Other Personal Cloud** command to join another Iomega Personal Cloud .
2. In the Add Trusted Device to Personal Cloud dialog box, enter the Personal Cloud name, username, and password you received in the email invitation.
3. Enter a descriptive name for your trusted device in the Description field.
4. Click **Apply**.

After applying this information, you are automatically connected to the Personal Cloud.

How do I ...

[enable security on my StorCenter ix2-dl](#)

[create an Iomega Personal Cloud](#)

[configure a Personal Cloud](#)

[invite people onto your Personal Cloud](#)

[use Copy Jobs with a Personal Cloud](#)

[delete a trusted device](#)

Managing Trusted Devices on a Personal Cloud


As an Iomega Personal Cloud administrator, you can manage trusted devices on your Personal Cloud. Trusted devices can be disconnected, or you can completely delete a trusted device from the Personal Cloud.


Disconnecting Trusted Devices

Click **My Personal Cloud**, and expand the trusted device section of the page.

To disconnect a trusted device from the Personal Cloud, disable the trusted device by clicking the switch to Disabled, and click **Yes** in the confirmation pop-up window. The trusted device is not deleted and can be reenabled at a later time.

Deleting Trusted Devices

To delete a trusted device from the Personal Cloud, click  next to the device's name. The trusted device is deleted and can only be added again by a user with trusted device privileges.

1. On the Personal Cloud page, expand the Trusted Devices section.
2. Click  next to the trusted device you want to remove from the Personal Cloud.
3. Confirm the deletion.

How do I ...

[join a trusted device](#)

[enable security on my StorCenter ix2-dl](#)

[create an Iomega Personal Cloud](#)

[configure a Personal Cloud](#)

[invite people onto your Personal Cloud](#)

[use Copy Jobs with a Personal Cloud](#)

Using Copy Jobs with an Iomega Personal Cloud

You can create [Copy Jobs](#) that can transfer data from one [trusted device](#) to another through the Personal Cloud. When you add a trusted device to your Personal Cloud, a Copy Jobs icon displays next to that device in the trusted device table. Clicking the Copy Jobs button opens the Copy Jobs page to help you configure a Copy Job between the Iomega StorCenter ix2-dl that is hosting the Personal Cloud and a trusted device. For more information on setting up Copy Jobs, refer to [Adding Copy Jobs](#).

How do I...

[create a Personal Cloud](#)

join a trusted device to a Personal Cloud

[add a Copy Job](#)

[enable security on StorCenter ix2-dl](#)

Disabling or Deleting Your Iomega Personal Cloud

When you disable your Personal Cloud, you are eliminating access to your Personal Cloud without deleting the account information you created when you set up the Personal Cloud. Later, if you want to reenable your Personal Cloud, you can without reentering all the account information. To completely stop the Personal Cloud and eliminate any account information with it, delete it. If you delete your Personal Cloud and later decide you want to recreate it, you must start the creation process again and re-invite all users. When you delete a Personal Cloud, you lose your ownership of its name.

To disable a Personal Cloud, click **Disable**.

To delete a Personal Cloud, click **Settings** and then click **Delete** in the Personal Cloud Settings dialog box.

How do I...

[create a Personal Cloud](#)

[invite people onto your Personal Cloud](#)

[join a trusted device to a Personal Cloud](#)

[configure my Personal Cloud](#)

[enable security on StorCenter ix2-dl](#)

Accessing Content Using Your Iomega Personal Cloud

You can share content by inviting users to your Personal Cloud. The data in Shares can be made accessible to all users of the Cloud, or access can be restricted to a specific set of users by setting access permissions to Shares. Access permissions control whether users are only allowed to read files in Shares, or if they can also write (upload) files to Shares.

How do I ...

[create an Iomega Personal Cloud](#)

[add users](#)

[create Shares](#)

[set access permission for Shares](#)

Informing Users What to Do with Iomega Personal Cloud

Personal Cloud enables users to access your Iomega device from the web. They can enter myCloudName.Myiomegacloud.com in a web browser, and when prompted, enter a valid username and password for your Iomega device . After they access your Iomega StorCenter , they can view Shares, upload and download content, and stream content. Optionally, they can install Iomega Storage Manager on their computers, and then join their computers as trusted devices to the Personal Cloud. When users join their computer as a trusted device to the Personal Cloud, they are making their machine and its files available to other users of the Personal Cloud. A large virtual network is created.

How do I ...

[create an Iomega Personal Cloud](#)

[add users](#)

[invite people to a Personal Cloud](#)

[join a trusted device to a Personal Cloud](#)

[enable security on Iomega device](#)

Sharing Content Using Social Media

Sharing Content using Social Media: Overview

If you have an account with social media services such as Facebook, Flickr, or YouTube, you can share content on your Iomega StorCenter ix2-dl with your friends and family using one or more of these social media sites. To share your content using social media sites, create Shares called [Active Folders](#), and connect each Active Folder with a social media account. Refer to the help topic links below for more information on these procedures. When you add photos and movies to an Active Folder, those files are automatically uploaded to the social media site associated with that Active Folder. If you have photos or movies you want to share with others, this is a great way to make your content available to people who may not have access to your StorCenter ix2-dl .

If you have configured a Personal Cloud on your StorCenter ix2-dl , you can grant Personal Cloud users access to Shares and Active Folders. This is useful if you want to allow users to add files to your social media sites. For example, if your StorCenter ix2-dl has a Flickr Active Folder, you can grant Personal Cloud users access to that Active Folder. In this manner, when photos are added to the Flickr Active Folder, either by you or by Personal Cloud users, those photos are uploaded automatically to your Flickr account.

Note that an Active Folder can only be associated with one social media account. For example, if you want Active Folders for your Facebook and YouTube accounts, create two Active Folders, and assign one Active Folder to Facebook, and one to YouTube. Using this example, any photos you add to your Facebook Active Folder are automatically uploaded to your Facebook page, and any movies you add to your YouTube Active Folder are automatically uploaded to your YouTube page. Not only is this a fast and easy way to share content, but uploading content to your social media sites provides an additional backup of your content, as the content is stored both on your StorCenter ix2-dl and at your social media accounts.

How do I...

[make a Share an Active Folder](#)

[upload to Facebook](#)

[upload to Flickr](#)

[upload to YouTube](#)

Facebook

Facebook is a social network to connect with friends and family. You can configure a [Share](#) as a Facebook Active Folder so that photos and movies added to that Share are automatically uploaded to your Facebook account.

Refer to [Managing Shares](#) for more information on managing Shares and Active Folders.

Note: If you do not have a Facebook account, go to the Facebook website to open an account.

Configuring a Facebook Active Folder

1. From the Iomega StorCenter ix2-dl Console , click **Shares**.
2. Select a Share to use as a Facebook Active Folder, and click to expand the Active Folder section.
3. Check **Enable**.
4. Select **Facebook** from the drop-down menu.
5. Click **Configure Facebook account access** to configure your Facebook account. You will be taken to a Facebook page to configure your account. Follow the instructions provided by Facebook.
6. Check **Delete files after upload** to delete images or movies from the Share once they are transferred to your Facebook account.
7. Images can also be resized prior to upload. Check 800x600, 1024x768, or enter a custom resolution for resizing images.
8. Click **Apply** to save your changes.

Once configured, all your images in this Active Folder will upload to your Facebook account.

9. Click **View Transfer History** to see the transfer activity from this Share to your account.

How do I...

[add a Share](#)

[make a Share an Active Folder](#)

Flickr

Flickr is a photo sharing network for sharing photos with friends and family. You can configure a Share as a Flickr Active Folder so that images and albums added to that Share are automatically uploaded to your Flickr account.

Refer to [Managing Shares](#) for more information on managing Shares and Active Folders.

Note: If you do not have a Flickr account, go to the Flickr website to open an account.

Configuring a Flickr Active Folder

1. From the Iomega StorCenter ix2-dl Console , click **Shares**.
2. Select a Share to use as a Flickr Active Folder, and click to expand the Active Folder section.
3. Check **Enable**.
4. Select **Flickr** from the drop-down menu.
5. Click **Configure Flickr account access** to configure your Flickr account. You are taken to a Flickr page to configure your account. Follow the instructions provided by Flickr.
6. Check **Delete files after upload** to delete images from the Share once they are transferred to your Flickr account.
7. Click **Apply** to save your changes.
8. Once configured, all images added to this Active Folder are uploaded to your Flickr account. Click **View Transfer History** to see the transfer activity from this Share to your account.

How do I...

[add a Share](#)

[make a Share an Active Folder](#)

YouTube

YouTube is a social media site to share video content. You can configure a Share as a YouTube Active Folder so that videos added to that Share are automatically uploaded to your YouTube account.

Refer to [Managing Shares](#) for more information on managing Shares and Active Folders.

Note: If you do not have a YouTube account, go to the YouTube website to open an account.

Configuring a YouTube Active Folder

1. From the Iomega StorCenter ix2-dl Console , click **Shares**.
2. Select a Share to use as a YouTube Active Folder, and click to expand the Active Folder section.
3. Check **Enable**.
4. Select **YouTube** from the drop-down menu.
5. Check **Delete files after upload** to delete videos from the Share once they are transferred to your YouTube account.
6. Click **Apply** to save your changes.
Once configured, all videos added to this Active Folder automatically upload to your YouTube account.
7. Click **View Transfer History** to see the transfer activity from this Share to your account.

How do I...

[add a Share](#)

[make a Share an Active Folder](#)

Share Content through Iomega Personal Cloud

You can share your multimedia content with friends and family through an Iomega Personal Cloud . Refer to the [Iomega Personal Cloud](#) section for more information.

How do I ...

[create an Iomega Personal Cloud](#)

[know my Personal Cloud content is secure](#)

Media Management

Media Management Overview

The StorCenter ix2-dl has a built-in media server that, when turned on, scans for media content in specific Shares that have media sharing enabled. Any media content contained in these specific Shares are accessible to any user on your network with a media player, even if the Share is secured. For information on enabling a folder as a media folder, refer to [Managing Shares](#).

Scanning for media content

The Media Server automatically scans for media content on a regular basis. However, you can click **Scan now** at any time to force the media server to perform an immediate scan for media content. This is especially useful after you have created new folders with media sharing enabled and copied a large amount of media content to them.

How do I...

[share media content over the internet](#)

[enable media aggregation](#)

[stream music, movies, and pictures](#)

[share media through social media](#)

Media Services Capabilities and Limitations


One important consideration when using the media server is that it can share media content on your StorCenter ix2-dl with anyone on the internet. When media sharing is enabled, internet users, including those users on mobile devices running the Iomega Link, can access media content on your StorCenter ix2-dl .

Note: When you enable internet access to your media content, all media content is available to any user on the internet, regardless of any security you may have applied to a media file. All your pictures, movies, and music are available to anyone accessing your StorCenter ix2-dl . You should be sure you want to make all your media content this accessible.

Sharing Media Content over the Internet

There are two methods for sharing media content on your Iomega StorCenter with anyone on the internet. You can enable internet access on the Media Server page. Alternatively, if you have, or plan to create an Iomega Personal Cloud on your Iomega StorCenter, you can enable internet access by [configuring your Iomega Personal Cloud](#).

Enabling Internet Access from the Media Server Page

1. On the Media Server page, click  Settings.
2. In the dialog box, check **Enable internet access**.
3. Click **Apply** to save your changes.
4. In the confirmation dialog box, check **Check this box to continue**.
5. Click **OK** to save your selection or click **Cancel**.

To access media content, internet users enter a non-secure IP address in their browser along with the port number 50599 used to access the media server, for example, <http://72.xx.xxx.104:50599>, where "x" is the IP value for your network. When a user enters this IP address, the Twonky Server page on the Iomega StorCenter displays. Refer to the Support section of the Twonky Server page for information on using the server. Iomega Link users can access media content directly from the Iomega StorCenter. Refer to your Iomega Link documentation for details.

For additional information on enabling internet access, refer to [Media Services Capabilities and Limitations](#).

How do I...


[scan for media content](#)

[enable media aggregation](#)

[stream music, movies, and pictures](#)

Media Aggregation

If you have multiple Digital Living Network Alliance (DLNA) servers in your network that have media content, you can combine all media content into one view by enabling aggregation on your Iomega device. When you enable aggregation, all media content on DLNA servers is available for playback using a DLNA player, such as Playstation®3, Windows Media Player®, or Xbox 360®. In addition, you can optionally copy all media content from your network servers to your Iomega device.

To set up media aggregation, click  **Settings** and choose one of the following options:

- **None** – Media aggregation is off. This is the default setting.
- **Show Common View** – This enables media aggregation and allows all media content from computers on the network to be played back by a DLNA player. All your movies, music, and pictures are linked from various computers and can be played back from one view. All aggregated media files remain on their original device, and can only be played while that device is powered on and connected to the network.
- **Copy Files** – This enables media aggregation and automatically copies all media content from computers, both networked and local, to your Iomega device. All your movies, music, and pictures from various computers can be played back from one view, and they are copied into Shares on your Iomega device. Because all media files are copied to the Iomega device, they can be played even if the original device they were on is powered off or not connected to the network.
- **Copy on Request** – This enables media aggregation but does not automatically copy all media content from computers, both networked and local, to your Iomega device. Computers on the network will have to enable media aggregation individually and then media files are copied to the Iomega device. If a computer is running the Iomega Storage Manager, media aggregation is automatically enabled.

Note: When you enable media aggregation, the media server restarts, and any media you are currently streaming stops playing. You can begin streaming your media after the media server has restarted.

Social Media Sharing

You can share media content, such as movies and pictures, using social media sites like Facebook, Flickr, or YouTube. Refer to the [Sharing Content Using Social Media](#) section for more information.

How do I ...

[share content through Facebook](#)

[share content through Flickr](#)

[share content through YouTube](#)

Streaming Music, Movies, and Pictures

The Media Server supports playback of videos, music and pictures from any UPnP AV (Universal Plug and Play Audio Visual) network media players, such as Playstation3, Windows Media Player, or Xbox 360.

You can play back all your media files from your individual home computers by enabling [media aggregation](#) on your lomega StorCenter . You can also connect USB mass storage devices (such as your iPod, mp3 player, or USB drive) to your lomega StorCenter and directly stream files through the device, or access media files through a networked media player. Below are two examples of how to set up the following media players:

- [iTunes](#)
- [Xbox 360](#)

Note: The procedures shown below are intended as examples. Your media player or version may operate differently. It is recommended that you refer to your media player documentation for instructions on how to add a network device.

Example: Setting up iTunes

1. Locate the source directory of your iTunes media content.
2. Drag, or copy, your existing media content to a Share that has media sharing enabled.
3. When you open the iTunes Library, iTunes will display all of the media content from the lomega StorCenter .

Example: Setting up Xbox 360

1. Connect your Xbox 360 to your TV and to the same local network as your lomega StorCenter .
2. Navigate to the **Media** Tab in Xbox 360 and select a media-enabled Share.
3. Select **Computer** from the options menu.
4. Click **Yes, Continue** when asked if you have downloaded and installed media sharing software on your computer, since the lomega StorCenter device comes preconfigured with this software.
5. Select lomega StorCenter from the list of names. You should now see all the public media content on your device.

How do I ...

[enable media aggregation](#)

[learn more about social media sharing](#)

Photos

Photos Overview

Your Iomega device has multiple ways to manage your pictures.

Your Iomega device can:

- Stream pictures that are in Shares with media sharing enabled
- Display pictures on the Home Page in a slideshow
- Automatically resize pictures
- Transfer pictures from your digital camera
- Upload pictures to social media sites like Flickr or Facebook

How do I ...

[stream pictures](#)

[display pictures in a slideshow](#)

[automatically resize pictures](#)

[transfer pictures from a digital camera](#)

[upload pictures to Facebook](#)

[upload pictures to Flickr](#)

Streaming Pictures

The Iomega StorCenter has a built-in media server that, when turned on, can scan for pictures in specific folders that have media sharing enabled. Any pictures contained in these specific folders will then be accessible to any user on your network with a media player. For information on enabling a folder as a media folder, refer to [Managing Shares](#).

Scanning for Pictures

The Media Server automatically scans for media content on a regular basis. However, you can click **Scan now** at any time to force the media server to perform an immediate scan for pictures. This is especially useful after you have created new folders with media sharing enabled and copied a large amount of media content to them.

How do I ...

[display pictures in a slideshow](#)

[automatically resize pictures](#)

[transfer pictures from a digital camera](#)

Creating a Slideshow on the Device Home Page

Your StorCenter ix2-dl can display a slideshow on its home page.

On the Home Page Settings feature page, check **Display slideshows** to display picture slideshows from folders on the StorCenter ix2-dl . Click **Manage slideshows** to configure any slideshows you want to display. The slideshow location can be any folder attached to the StorCenter ix2-dl , including a USB drive or DFS location.

Automatically Resizing Your Photos

A Photo Resize Active Folder automatically changes the size of photos in that Share to a set size. You can choose to keep the original photos added to this Share, while a resized copy is created. The resized photos are saved to a folder on the Share named by the photo size you choose, such as 800x600. To configure a Share as a Photo Resize Active Folder, access Shares from the Iomega StorCenter ix2-dl Console, select a Share, and expand the Active Folders section to enable and configure it.

Refer to [Managing Shares](#) for more information on managing Shares and Active Folders.

Configuring a Photo Resize Active Folder


1. From the Iomega StorCenter ix2-dl Console, click **Shares**.
2. Select a Share to use as a Photo Resize Active Folder, and click to expand the Active Folder section.
3. Check **Enable**.
4. Select **Photo Resize** from the drop-down menu.
5. You can set a size for your pictures. Select 640x480, 800x600, 1024x768, or enter a Custom Resolution for resizing images. The resized photos are saved to a folder on the Share named by the photo size you choose, such as 800x600.
6. You can keep a copy of the original by selecting **Keep the original files after resizing**.
7. To add a watermark to your photo, select **Add a watermark to the photos**. Click the Watermark file icon to apply a watermark image to your file.
8. Click **Apply** to save your changes.
9. Once configured, all photos added to this Active Folder are resized to your settings. Click **View Content** to see the files in this Share.

How do I...

[manage a Share](#)

Getting Pictures from Your Camera

The Picture Transfer Protocol (PTP) allows pictures to be automatically copied from a USB camera connected directly to the StorCenter ix2-dl . When Picture Transfer is turned on, and your camera is connected to your StorCenter ix2-dl , the pictures are copied to the configured destination folder.

1. Open the Picture Transfer page, click the switch on.
2. Optionally, if you want to automatically delete the pictures from your camera once they have been safely copied to your Iomega StorCenter, check **Remove Copied Pictures From Camera** to automatically delete the pictures from your camera once they have been safely copied to your StorCenter ix2-dl .
3. Click  to open the Select Folder pop-up window, and select a Share as the destination for your pictures.

Music

Music Overview

If you have music files in media-sharing enabled folders on your Iomega StorCenter, those music files can be streamed by a DLNA player running on a computer on the network.

How do I ...

[stream music](#)

Streaming Music

The Iomega StorCenter has a built-in media server that, when turned on, scans for music in specific folders that have media sharing enabled. Any music contained in these specific folders is then accessible to any user on your network with a media player. For information on enabling a folder as a media folder, refer to [Managing Shares](#).

Scanning for Music

The Media Server automatically scans for media content on a regular basis. However, you can click **Scan now** at any time to force the media server to perform an immediate scan for media content. This is especially useful after you have created new folders with media sharing enabled and copied a large amount of media content to them.

Torrents

Torrent Overview

Torrent downloads allow you to share files using a peer-to-peer file sharing protocol. With torrent download enabled, you can download files using the torrent protocol to your Iomega StorCenter and then those files can be uploaded by other torrent users.

After you have added torrent jobs to your torrent share, the torrent download page displays a table of torrent jobs, showing both downloads and files available for upload. Multiple torrent files can download simultaneously. The table information includes the name of the file, its size, download or upload status, and amount of time remaining for the torrent job to complete.

How do I ...

[enable torrent downloads](#)


[configure a router for torrent downloads](#)

[delete torrent jobs](#)


[share torrent downloads with other peers](#)

[add torrent files to your Iomega StorCenter](#)

Enabling Torrent Downloads

1. On the Torrent Download page, click the switch on.
2. Click  **Settings** to modify the torrent download and upload settings.
3. In the Torrent Download Settings dialog box, enter a value for **Maximum Download Speed**. This sets the rate at which files are downloaded to your device. The maximum download speed you can enter is 2 MB/s.
4. Enter a value for **Maximum Upload Speed**.
This sets the speed at which other users can upload a file unprompted from your device. The upload speed can affect device performance, so it is recommended that you choose a value that does not strain the performance of your device and impact other work on it. The maximum upload speed you can enter is 1GB/s.
5. Set a **Port** value used by torrent peers to upload files from your StorCenter ix2-dl . The port value should be a number between 6881 and 6999, and your router must be configured to allow port forwarding on the same port. Refer to [Configuring your router for torrent downloads](#) for more information on how to do this.
6. Click **Apply** to save your changes.

Deleting torrent jobs

1. On the Torrent Download page, select a torrent you want to delete.
2. Click the  under the Action column to delete the torrent.
3. Click Yes to delete the torrent.

Configuring Your Router for Torrent Downloads

You must manually configure your router to forward a specific port to your StorCenter ix2-dl . Most routers refer to this as port forwarding or application access, and it is recommended that you refer to your router's documentation to learn how to set these values.

Port Information Used to Configure Your Router

The following information may be required to manually configure your router:

Forward the port to your StorCenter ix2-dl IP address identified in the table:

Device IP Address

192.168.1.1

Port name

HTTP

Port number

Set to the same port value set on the Torrent Download page.

Protocol

TCP

Torrent Active Folders

Sharing Torrent Downloads with Other Peers

Torrent downloads allow you to share files using a peer-to-peer file sharing protocol. With Torrent Download, you can download files using the torrent protocol to your StorCenter ix2-dl and then those files can be uploaded by other torrent users.

Refer to [Managing Shares](#) for more information on managing Shares and Active Folders.

Configuring a Torrent Active Folder

1. From the Iomega StorCenter ix2-dl Console , click **Shares**.
2. Select a Share to use as a Torrent Active Folder, and click to expand the Active Folder section.
3. Check **Enable**.
4. Select **Torrent** from the drop-down menu.
5. Click **General torrent settings** to set up Torrent settings. Refer to [Torrent Downloads](#) for more information on configuring your Torrent downloads.
6. Click **Apply** to save your changes.
7. Click **View Content** to see the files in this Share.

How do I...




[manage a Share](#)

Adding Torrent Files to Your StorCenter ix2-dl

1. Open the Shares page.
2. Expand the Share that is enabled as a Torrent Active Folder. Any Share can be enabled as a Torrent Active Folder. For information on enabling a Torrent Active Folder, refer to [Torrent Active Folders](#).
3. Copy the downloaded torrent file to the Torrent Active Folder Share. The torrent file immediately starts to download to the Share. An administrator user can monitor its download progress on the [Torrent Download](#) page. All users can monitor the download progress through the [Content Viewer](#) on the Torrent Share.

Managing Torrent Downloads

In the Content Viewer, you can perform the following actions on torrents:

- Pause or resume a torrent job. Click  to pause a torrent download. When a torrent download is paused, you can resume the download by clicking .
- Delete a torrent job. Click  to delete the torrent download.

Videos

Video Capabilities Overview

Your Iomega StorCenter has multiple ways to manage your videos.

Your Iomega device can:

- Stream movies that are in Shares with media sharing enabled
- Upload videos that are added to Shares associated with social media sites
- Record videos for video surveillance

How do I ...

[stream movies](#)

[share movies through social media](#)

[enable video surveillance](#)

Streaming Movies

The Iomega StorCenter has a built-in media server that, when turned on, scans for movies in specific folders that have media sharing enabled. Any movies contained in these specific folders are accessible to any user on your network with a media player. For information on enabling a folder as a media folder, refer to [Managing Shares](#).

Scanning for Movies

The Media Server automatically scans for media content on a regular basis. However, you can click **Scan now** at any time to force the media server to perform an immediate scan for movies. This is especially useful after you have created new folders with media sharing enabled and copied a large amount of media content to them.

Video Surveillance

Video Surveillance Overview

The Video Surveillance page lets you add and configure cameras connected to your Iomega StorCenter ix2-dl, view live video, and see video alerts. The page has three primary links:

- **Add Video Camera** — Manually adds a video camera to your StorCenter ix2-dl if it is not automatically discovered. Refer to [Adding a Video Camera](#).
- **Video Wall** — Displays live video from all video cameras configured with your StorCenter ix2-dl. The video from all cameras is displayed in a grid.
- **Alerts** — Displays alert messages about the video surveillance feature. Refer to the camera configuration pages for camera status information.

Video Surveillance features

The Video Surveillance page displays the **Name**, **Space**, and **Model** information of each video camera connected to the StorCenter ix2-dl, along with **Action** controls for each video camera. Administrators have access to modify these settings.

Note: When no supported cameras are connected to your network, this page will be empty.

Name

This section displays the video camera's IP address, name, login username, and the destination folder for the video recording files. Additionally, using the **Camera Configuration** link, you can modify the video camera software configuration settings using the video camera's native software. It also displays an icon that indicates the current state of the video camera. The possible states are:



The video camera is no longer connected to the network.



The video camera is no longer connected to the network, but a recording schedule is set for it. You should delete this video camera if it is no longer on the network, or fix the network connection so it can record as scheduled.



The video camera is connected to the network and is currently recording. There is no schedule for this recording, since it was started manually. The recording must therefore be stopped manually.



The video camera is connected to the network, a recording schedule is set, and the camera is currently recording.



The video camera is connected to the network and a recording schedule is set for it, but it is not currently recording.



The video camera is connected to the network, but no recording schedule is set.

Space




The Space column identifies how much disk space is currently used by the video files in the destination folder for this video camera.

Model

This column lists the model information for this video camera.

Action

For each video camera, you can perform the following actions:

- Click either  to manually start recording or  to stop recording. These buttons are available only for video cameras that are currently connected and accessible on the network. Use the manual start and stop record buttons to start recording at any point and to stop a recording until the next scheduled start time.
 - **Note:** During recording, if you want to change the camera resolution and frame rate, you must stop recording, change the values on the camera's configuration page, and then start the recording again.
-
- Click  to open a live view from your video camera. You may be prompted to supply the username and password for the video camera.

How do I...

[add a video camera](#)

[manage a video camera](#)

[delete a video camera](#)

Adding a Video Camera

You can use the Video Surveillance page to manually add supported video cameras if they are not discovered automatically on your StorCenter ix2-dl . The Video Surveillance page also displays the current settings for any video camera attached to your network. For example, you might have video cameras on a summer house in one geographic location, while your StorCenter ix2-dl is in another geographic location.

If your video camera is already listed, you can modify its settings. To manually add a video camera, reference the instructions below.

Manually Adding a Video Camera

Follow the instructions below to add your video camera, set a retention policy for your saved recordings, and schedule your video surveillance recordings.

1. On the Video Surveillance page, click **Add Video Camera**.
2. In the Video Camera Information section, enter the following about your video camera:

Note: If your video camera is automatically discovered, information like **Name** and **Manufacturer** are already filled in for that video camera. These settings can be modified. If you modify these settings, you must make the same changes to the associated settings on your camera's configuration page.

- Name
 - Camera Login Password
 - IP Address
 - HTTP Port: A camera that is automatically discovered will periodically receive configuration values, including the HTTP port number, from the actual camera. If you change the HTTP port number on a camera's configuration page, but do not change it on the Video Surveillance page, that camera will be offline on the Video Surveillance page until the camera receives the updated value. If you manually add a camera and change its HTTP port number on the camera's configuration page, the camera displays as offline on the Video Surveillance page. Delete the camera and add it again, using the updated HTTP port value.
 - RTSP Port
3. Select a Destination Folder for the video camera recordings. Recorded video files are saved to this folder, and the StorCenter ix2-dl automatically organizes your saved video recordings into folders by video camera name. Within each video camera folder are sub-folders that organize the recordings by date. For example, if you set the destination Share to Media/Videos and the name of your camera is HomeDoor, a recording made on July 17, 2011, can be found at Media/Videos/HomeDoor/20110717.
 4. Click **Camera Configuration** to link your video camera's software.

Note: If you want to change the camera resolution and frame rate, you must change them on your camera's configuration page.

5. Click **Apply** to save your changes. Click **Cancel** to discard your unchanged settings.

The video camera displays in the table. For additional setup, refer to the sections on [Retention Policy](#) and [Scheduling](#).

Managing Video Cameras

You can set a retention policy on your recordings and also schedule when to record.

Setting a Retention Policy

Setting the retention policy determines how much recorded video you keep on your Iomega StorCenter . Retention is set one of two ways:

- Maximum days to save recordings
- Maximum space for recordings




Click **Apply** to save your changes.

If you select **Maximum days to save recordings**, enter a value in days. If you select **Maximum space for recordings**, enter a value in gigabytes. Setting this value too high may consume all available space, while setting this value too low may cause recordings to be deleted sooner than you would like. The maximum space cannot exceed 90% of the total space on the Iomega device .

Scheduling the Recordings

Schedule the days and time periods you want your video camera to record.

1. Select **Schedule Recording** to enable the recording scheduler.
2. Select the days you want to record, or **All Days** for the entire week.
3. Choose the Start and Stop times for your recording.
4. Click **Apply** to save your changes.

Once your video camera is set, click  in the Action column to begin recording. To stop recording, click  . For a live view from your video camera, click  . The live view displays even when the video camera is not recording.

How do I ...

[add a video camera](#)

[delete a video camera](#)

Deleting Video Cameras

To delete a video camera, expand the Information section of the camera and click **Delete**.

How do I ...

[add a video camera](#)

[manage a video camera](#)

Adding Applications to Your Device

Application Overview

You can install supported applications on your StorCenter ix2-dl using the Application Manager page. For each application installed you may have the option to uninstall, start, and stop the application.

How do I...



[install an application](#)

Application Manager

The Application Manager page allows you to add applications to your StorCenter ix2-dl from an installation file located on your computer. For each application installed you may have the option to uninstall, start, and stop the application. This page shows the applications which came preinstalled with your StorCenter ix2-dl ; as well as applications that you have manually installed.

Note: Only valid applications built using the Iomega StorCenter SDK can be installed on your StorCenter ix2-dl .


Starting or stopping an application

When available, click  in the Action column to stop an application. Click  to start it again.

Adding applications

1. Click the **Add application** link. The Add application window displays.
2. Enter the path and name of the application file, or click **Browse**, and select the application file located on your computer.
3. Click **Upload** to install the application.

Removing applications

When available, click  in the Action column to uninstall an application.

How do I...

[enable security](#)


Upgrading Your Device


Software Updates



The Software Updates page identifies the StorCenter ix2-dl software status and provides the ability to update the software for the StorCenter ix2-dl .

This software is protected by RSA BSAFE technology.

Auto-update process: installing a device software update



1. In the table listing the current software installed on your StorCenter ix2-dl , click  in the Action column to check for updates.
2. The Status column will state whether the software is up to date or if an update is available.

To copy an update file to your StorCenter ix2-dl , click  . The software update file is downloaded directly to your StorCenter ix2-dl .



3. If multiple updates are ready, you may install all the updates at the same time. Click  **Apply all pending updates** to install the available updates. The software updates are applied to your StorCenter ix2-dl .
4. Once the software is installed, the StorCenter ix2-dl will reboot. If you are applying multiple updates, you only need to reboot once. Do not power down the StorCenter ix2-dl during this time.
5. If you want to remove the update without applying changes, click  in the Action column.

Caution: Do not shut down the StorCenter ix2-dl during the update process as this can damage the StorCenter ix2-dl . The StorCenter ix2-dl will be temporarily inaccessible during the software update. Be sure no critical files are being accessed.

Manual update process: installing a device software update

1. In the table listing the current software installed on your StorCenter ix2-dl , click  in the Action column to check for updates.
2. If an update is available, the Status column will state that a software update is available with a link. Download the update file to your local computer.
3. To retrieve the update, click  **Add Software**.
4. In the **Add Software** pop-up window, if an update is available, there will be a link to download the appropriate update for your StorCenter ix2-dl . Click the link, follow the instructions on the download site page, and download the software update to your local computer.
5. Once downloaded, click **Browse** to select the update, and then click **Upload** to continue.

When the update is uploaded to the StorCenter ix2-dl , the Status column will say **Ready to apply**.

6. Click  **Apply all pending updates** to apply the update or updates. The software updates will be applied to your StorCenter ix2-dl . If you want to remove the update without applying changes, click  in the Action column.

The StorCenter ix2-dl restarts once the software is installed. You should not power down the StorCenter ix2-dl during the installation process as this can damage the StorCenter ix2-dl . If multiple updates are ready, all of them will be applied, requiring only one reboot.

Caution: The StorCenter ix2-dl will be temporarily inaccessible during the software update. Be sure no critical files are being accessed.


Recovering Your Device Configuration

Copying Your Iomega StorCenter ix2-dl Settings to Other Devices


The Configuration Backup and Restore page allows you to back up and restore system configuration information. Backing up a configuration saves various system properties, including users, groups, device identification, and Share names and permissions. Configuration information is saved to a file, and you can save as many versions of the file as you want. After backing up the configuration, you can restore it to your StorCenter ix2-dl at any time. You can also apply the configuration backup to other Iomega StorCenter devices of the same model, effectively using the configuration as a template.

Note: Configuration Backup and Restore does not back up or restore any data files on your StorCenter ix2-dl .

Backing up Device Configuration

1. On the Configuration Backup and Restore page, click  **Back up configuration** to select a name and location for your configuration backup.
2. Save the configuration file to an external device, such as your computer or a USB drive. You can save as many configuration backups as you want.

Restoring a Configuration Backup

1. On the Configuration Backup and Restore page, click  **Restore configuration** to select a saved configuration backup.
2. In the Restore Configuration dialog box, click **Browse** to locate a previously saved configuration backup stored on your computer or USB device.
3. Select one of the following options:
 - **Restore settings** – overwrites any existing settings, such as device identification and Share names. When you select this option, existing data on the StorCenter ix2-dl is not deleted, and the configuration restore operation starts automatically after you click Apply in the Restore Configuration dialog box.
 - **Restore settings and drive configuration** – deletes all data, users, and settings from the target StorCenter ix2-dl . If you select this option, a confirmation dialog box displays and informs you that restoring the configuration will delete all data and overwrite any existing users or settings on the target StorCenter ix2-dl . Check **Check this box to continue** to confirm this dialog box or click **Cancel** to stop the configuration restore process.
4. Click **Apply** to save your changes. After you click Apply, the restore process starts.
5. If your source StorCenter ix2-dl had Active Directory enabled, you are prompted to enter the administrator name and password of an account that has the rights to join the domain.
6. Click **OK**.

Hardware Management

About the StorCenter ix2-dl Components

This topic describes the front and rear panel components of the StorCenter ix2-dl.

Front Panel



Status Indicators, Buttons and Ports

1. Power/Status Indicator – Displays the current operational status of the StorCenter ix2-dl.

- Solid White – StorCenter ix2-dl is healthy.
- Flashing White – Flashes when the StorCenter ix2-dl is starting up or shutting down.
- Flashing Red – System or drive error. System software will indicate error.
- Alternating White and Red: System software will indicate error.

2. Drive Activity Indicator – Displays the current drive status of the StorCenter ix2-dl.

- Solid Blue – StorCenter ix2-dl drive is healthy.
- Flashing Blue – Read/Write activity.
- Solid Red – Drive error. System software will indicate error.

Rear Panel



1. **Security Lock** – Connect a security cable to prevent theft.
2. **Power Button** – Use the power button to power the StorCenter ix2-dl on and off.
3. **USB Connector** – Supports devices such as USB storage devices and printers.
4. **Gigabit Ethernet** – High-speed Ethernet connector that will automatically detect your network speed (10/100/1000Base-T).
5. **Reset Button** – Hold the RESET button for four seconds to reset security and network settings. This allows you to regain access if network settings are incorrect or you've forgotten your password.
6. **Power Connector** – Plug the power cord into this connector.

Energy Saving

The Energy Saving page provides power settings for the StorCenter ix2-dl .

Power Down Drives

Click the Power Down Drives drop-down menu to select how much idle time should be allowed to elapse before the StorCenter ix2-dl powers down the drives. Drives automatically power back up when the StorCenter ix2-dl accesses them. You may notice a slight delay when the drives are accessed.

Brightness

To adjust the brightness of the lights on the StorCenter ix2-dl , set the **Indicator Brightness** to High, Medium, or Low.

Factory Reset

Factory Reset returns the StorCenter ix2-dl to its original state. This feature is useful if you give your StorCenter ix2-dl to someone else.

Factory Reset provides two options for returning your StorCenter ix2-dl to its original state:

- **Quickly delete all data** – permanently deletes all record of existing or deleted data, users, and passwords.
- **Securely delete all data** – this option takes significantly longer, but provides an added security benefit by permanently erasing all data on the drives to prevent recovery of existing or deleted data, users, and passwords. The secure delete operation renders all data irrecoverable.

Note: You can use the factory reset feature only to erase the drives internal to the StorCenter ix2-dl . You cannot use this feature to reset any external storage devices that may be connected.

1. Choose one of the following options:
 - Quickly delete all data
 - Securely delete all data
2. From the **After Reset** drop-down menu, choose to **Restart** or **Power off** the StorCenter ix2-dl after the factory reset completes.
3. Click **Apply**.
4. In the pop-up confirmation, click **Yes** to perform the factory reset. After the factory reset completes, the StorCenter ix2-dl powers down or restarts depending on your selection.

Warning: When you quickly delete or securely delete all data on your Iomega StorCenter, any installed applications, as listed on the [Application Manager](#) page, are also deleted. Go to www.lifelineapps.com to download and reinstall your applications. In addition, you should visit the Iomega support web site for specific information on reinstalling applications that came preloaded with your StorCenter ix2-dl .

UPS Management

The Iomega StorCenter UPS Management page allows you to monitor the status of an attached Uninterruptible Power Supply.

If your StorCenter ix2-dl is connected to a UPS battery backup unit, it is listed on this page. The battery status of the backup unit is also indicated, displaying how much of a charge is left in the battery. To monitor the battery status of your UPS unit, connect your StorCenter ix2-dl to it with a USB cable.

If the StorCenter ix2-dl is running from the UPS battery, it automatically shuts down to preserve data as the battery charge gets low.

Adding New Drives to Your Iomega StorCenter ix2-dl

StorCenter ix2-dl devices with multiple drives allow you to add new drives while the device is powered on.

Note: You can add one or both drives on a StorCenter ix2-dl . If you are using an Iomega StorCenter ix2, you can add only one drive at a time.


To install new hard drives in your StorCenter ix2-dl :

1. Mount the drive carrier containing the new drive in an available slot.
2. A confirmation dialog box displays as soon as the StorCenter ix2-dl detects the new hard drive. Click **Yes** to proceed.

Note: All data on the drive is deleted.

3. You are re-directed to the Iomega StorCenter ix2-dl Console .
4. Access the **Drive Management** page.
Your StorCenter ix2-dl displays the new hard drives in the bays they are mounted in.
5. To create a RAID Array, you must install a minimum of two hard drives. The same confirmation dialog box displays. Click **Yes** to proceed.

Note: You can create a Storage Pool using one hard drive if desired. You will not have any RAID protection options and can only select **None** from the RAID dropdown list while configuring your Storage Pool.

6. When all new drives are detected, click  **Add a Storage Pool**.
7. Complete the Storage Pool configuration options and select the desired drives on which to build the Storage Pool by checking the boxes next to them.
8. Allow a few minutes for the RAID array and Storage Pool to build. When complete, the Storage Pool status displays on the Drive Management page.

Troubleshooting Routers

If you encounter a problem while connecting or using your StorCenter ix2-dl , check the topics listed below for possible solutions.

If you have properly set port forwarding on your router and remote access still does not work, you may have multiple routers on your network. In this situation you will most likely have two NAT (Network Address Translation) firewalls.

1. One of the easiest ways to identify this issue is to log in to the router to which the StorCenter ix2-dl is connected.
2. Once you have logged in, go to the page that shows the router's WAN IP address; usually Status or Network Info.
3. If the WAN IP address begins with 192.168, 10, or 172, you may have a NAT Firewall between the router and internet connection.

There are several options for resolving double NAT situations. The sections below explore the pros and cons of each resolution:

These instructions will refer to the router that is connected directly to the internet as the **Primary Router**. The cascaded router or router to which your StorCenter ix2-dl is connected is referred to as the **Secondary Router**.

- Use the primary router's DMZ
- Port forward the primary router to the secondary router
- Put the secondary router in bridging mode
- Put the primary router in bridging mode

Enabling the DMZ

Most routers have a feature called DMZ or Default Server. DMZ stands for Demilitarized Zone, Data Management Zone, Demarcation Done, or Perimeter Network. The DMZ allows you to enter an IP address that will exist outside the router's NAT Firewall.

This is the easiest way to configure your network to handle double NAT situations; however, it is dependent upon DMZ functionality within your primary router.

To enable the DMZ:

1. Log in to the primary router.
2. Navigate to the settings page for DMZ or Default Server. Refer to the documentation that came with your router for information on where this feature is found.
3. Enter the secondary router's IP address.
4. Save your settings.

Your secondary router is no longer behind your primary router's firewall. If port forwarding is correctly configured, remote access should now be working properly. Moving your secondary router into the DMZ should not have any effect on the security of the network, since it is still protected by the secondary router's firewall.

Configuring Port Forwarding on Double NAT Networks

If for some reason the network configuration cannot be changed and your setup requires the double NAT, you must perform the port forwarding steps twice. On the primary router, set the port forwarding to the cascaded router's external IP address. On the cascaded router, set the port forwarding to the StorCenter ix2-dl's IP address.

Bridging the Secondary Router

Make sure that the primary router (usually the one connected to or acting as the DSL/Cable modem) is the only one with DHCP (Dynamic Host Configuration Protocol) and NAT (Network Address Translation) enabled. The secondary should be changed to bridging mode. Ensure that the secondary router connects to the primary router using a standard port rather than the port labeled Uplink or internet. This turns your secondary router into a switch; however, you can still enable its Wireless Access Point if so equipped.

Refer to the documentation that came with your router for configuration information and settings.

Bridging the Primary Router

If none of the above options are available, you must enable transparent bridging on your primary router. This may require contacting your ISP (Internet Service Provider) to configure the DSL or Cable Modem/NAT into bridge mode, which then disables the first NAT/Firewall. After this first firewall in the modem is disabled, the secondary router handles all the network traffic, Port Forwarding, and allows Remote Access to work.

You should not attempt bridging without help from the ISP. If bridge mode is attempted by the customer and not configured properly, it can render the customer's internet connection inoperable. Primary router bridging may also require special configuration information and settings on the secondary router.

If you configured your StorCenter ix2-dl using DHCP, you may not be able to reconnect to it via Remote Access after a reboot. DHCP automatically receives an IP address from the server whenever the StorCenter ix2-dl restarts. This is a very simple way to configure the StorCenter ix2-dl but can cause problems with your router's port forwarding settings. The router does not dynamically update port forwarding settings and cannot port forward to your StorCenter ix2-dl if its IP address changes.

To resolve this problem, try one of the following processes:

- Increase the length of the DHCP lease: Your router attempts to remember all DHCP clients and assigns them the same IP address every time they request an IP address; however, the router forgets clients if they do not request an IP address for a certain amount of time. Your router has a setting for the duration of the validity of the DHCP lease. If your network requires DHCP, this may be a good solution; however, it is not always guaranteed to work. Occasionally updating your router's port forwarding settings may be required.
- Use Static DHCP: Some routers allow you to assign Static IP addresses through the DHCP system based on the MAC address of the device. This ensures that the StorCenter ix2-dl always gets the same IP address, and your port forwarding settings are always correct. Static DHCP allows you to leave your StorCenter ix2-dl in DHCP mode. Refer to your router's documentation for more information on configuring DHCP settings.
- Use a Manual IP Address: Changing the Manual IP address reduces the reliance of your StorCenter ix2-dl on the DHCP server; however, you must perform additional configuration for it to work properly.
 1. Log in to your router and write down the DHCP range it is using.

2. Refer to your router's documentation for more information on configuring DHCP settings.
3. Navigate to the IP address settings interface page on your StorCenter ix2-dl . For more information, check the Network Settings section of this manual.
4. Enter a new IP address that is outside of your router's DHCP range. For example, if your router is distributing IP addresses in the range of 192.168.14.2 through 192.168.14.50, you must assign the StorCenter ix2-dl a number between 192.168.14.51 and 192.168.14.255. Make sure you are assigning the StorCenter ix2-dl an IP address that is not in use by another device.
5. Enter a subnet mask. The subnet mask describes the size of your network. For most networks this is 255.255.255.0 which allows for 256 network devices. If you are on a larger network or are using the self-assigned APIPA range (169.254.x.x), you must use a 255.255.0.0 or larger subnet mask.
6. For best results, enter the IP address(es) for your DNS Server(s).
7. If necessary, enter the IP address(es) for your WINS server(s).
8. Enter a gateway address. In most cases, this is the IP address of your router.
9. If necessary, update your router's port forwarding information with the new static DHCP IP address.

Additional Support

How to Get Help

Iomega is committed to providing excellent customer support. To meet this goal, Iomega offers a variety of support options designed to meet the needs of a wide range of users. For complete information on the support options available for your Iomega product, visit the Iomega website. Please select your region carefully.

Here's just some of what is available on Iomega's award-winning web support site 24 hours a day, 7 days a week:

- Answers to frequently asked questions (FAQs)
- Online help pages with troubleshooting or basic how to information
- Up-to-date Iomega software and drivers
- Advanced online support options, such as 1-on-1 live chat and email
- Electronic copies of Iomega product manuals
- Information on telephone support options
- Information on advanced technical service options, such as data recovery
- Warranty information and product return instructions

Support options available may vary depending on your region and language of choice. Iomega's specific customer support policies (including fees for services) and procedures change as technology and market conditions dictate. To obtain information about Iomega's current policies, please visit our website at:

www.iomega.com

or write to:

Iomega Customer Service
4059 South 1900 West
Roy, UT 84067, USA

Support

The Support feature opens the Iomega web site where you can get more information about your Iomega StorCenter ix2-dl . The Support page provides access to content for learning more about using and supporting your StorCenter ix2-dl .

Refer to the [Iomega Support](#) site for more information.

Legal

StorCenter ix2-dl Trademark Page


lomega , the stylized logo, and StorCenter are either registered trademarks or trademarks of lomega Corporation in the United States and/or other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Mac, Macintosh, and AppleTalk are registered trademarks or trademarks of Apple Computer Inc. in the United States and/or other countries. Certain other product names, brand names, and company names may be trademarks or designations of their respective owners.

Regulatory Information

This topic provides regulatory information for various countries.

FCC (United States)

The computer equipment described in this manual generates and uses radio frequency (RF) energy. If the equipment is not installed and operated in strict accordance with the manufacturer's instructions, interference to radio and television reception might result.



This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Note: Changes or modifications to the electronics or enclosure of this product must be expressly approved by Iomega; otherwise, the user's authority to operate this product might be voided by the FCC.

Canadian Verification

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations (ICES-003, Class B).

This Class A digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

CE (European Community)

Iomega declares that this Iomega product conforms to all applicable European Directives and Standards, including by way of example, 2004/108/ EC, 2009/125/ EC, and 2006/95/ EC. The Declaration of Conformity can be obtained by contacting Iomega or is available at www.iomega.com/support/ce.

Manufacturer/Responsible Party

Iomega Customer Service, 4059 South 1900 West, Roy, UT 84067

EU Representative

Iomega International SA
H/O Iomega Netherlands
Hardwareweg 4
3821 BM Amersfoort
NL - The Netherlands



Waste Electrical and Electronic Equipment (WEEE)



In accordance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE), the presence of the above symbol on the product or on its packaging indicates that this item must not be disposed of in the normal unsorted municipal waste stream. Instead, it is the user's responsibility to dispose of this product by returning it to a collection point designated for the recycling of electrical and electronic equipment waste. Separate collection of this waste helps to optimize the recovery and recycling of any reclaimable materials and also reduces the impact on human health and the environment.

For more information concerning the correct disposal of this product, please contact your local authority or the retailer where this product was purchased.

Safety Information

Observe the following guidelines when using your Iomega StorCenter ix2-dl :

1. Follow all instructions marked on the StorCenter ix2-dl and in the documentation.
2. Use only the power supply cable provided with the StorCenter ix2-dl . Always use the appropriate power supply cable for your country.
3. Unplug the StorCenter ix2-dl before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use the StorCenter ix2-dl near water. Do not spill liquid on or into the StorCenter ix2-dl .
5. Do not place the StorCenter ix2-dl on an unstable surface.
6. Do not place the StorCenter ix2-dl near or on a radiator or heat register.
7. Openings in the StorCenter ix2-dl are provided for fans and air ventilation and should not be blocked or covered. Make sure the StorCenter ix2-dl has ample ventilation (at least 6 inches or 127 mm) in front and behind the unit. Do not place the StorCenter ix2-dl near or on a radiator or heat register.
8. Do not walk on the power cord or allow anything to rest on it.
9. There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Dispose of used batteries according to local, state, regional, and federal regulations.

Under any of the following conditions, unplug the StorCenter ix2-dl from the wall outlet and contact technical support:

- The power cord or plug is damaged.
- Liquid has been spilled into the device.
- The device does not function properly when the operating instructions are followed.
- The device was dropped or the exterior enclosure is damaged.

Limited Warranty

Drives and Media

- Coverage
- Excluded Products and Problems
- Remedies
- Obtaining Warranty Service
- Limitations

Coverage

Iomega warrants this hardware product to be free from defects in materials and workmanship for the warranty period. This non-transferable, limited warranty is only to you, the first end-user purchaser. The warranty begins on the date of purchase and lasts for a period of one (1) year for products purchased in the Americas, the Asia-Pacific region, or non-European Union nations in Europe, the Middle East, or Africa; ninety (90) days for Iomega reconditioned products purchased in these regions; or, two (2) years for products purchased by an end-user in member nations of the European Union. Customers who register their new products at www.iomegareg.com within 90 days of purchase will receive a warranty extension so that their total warranty shall be a period of three (3) years in all regions. Reconditioned products are not eligible for a warranty extension.

Excluded Products and Problems

This warranty does not apply to: (a) Iomega software products; (b) expendable components such as fuses or bulbs; or (c) third party products, hardware or software, supplied with the warranted product. Iomega makes no warranty of any kind on such products which, if included, are provided "AS IS." This warranty does not cover damage caused by accident, misuse, abuse, failure to follow instructions given in the product documentation, use of non-Iomega supplied or approved replaceable components, exposure of media to excessive magnetic fields, external environmental causes, or damage arising from any cause or causes for which Iomega is not responsible such as exposure to abnormal temperatures, shock, power surges, power, outages, improper power supply, or damage caused while the product is being shipped from you to Iomega .

Remedies

Your sole and exclusive remedy for a covered defect is repair or replacement of the defective product, at Iomega 's sole option and expense (shipping may be charged), and Iomega may use new or refurbished parts or products to do so. If Iomega is unable to repair or replace a defective product, your alternate exclusive remedy shall be a refund of the original purchase price.

The above is Iomega 's entire obligation to you under this warranty. IN NO EVENT SHALL IOMEGA BE LIABLE FOR INDIRECT, INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, USE, OR PROFITS EVEN IF IOMEGA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. In no event shall Iomega 's liability exceed the original purchase price of the drive or the media disk. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Obtaining Warranty Service

You must notify Iomega within the warranty period to receive warranty service. Just as technology and market conditions vary, Iomega 's specific customer support policies (including fees for services) and procedures change over time. To obtain information about Iomega 's current policies or warranty service, please visit our website at www.iomega.com/supportpolicy.html or write to:

Iomega Customer Service, 4059 South 1900 West, Roy, UT 84067

Contact information for Iomega Customer Service can be obtained on our support website at:

- Americas www.iomega.com/support
- Europe www.iomega.com/europe/support
- Asia www.iomega.com/ap/support

If your product is eligible for warranty service, you will be required to return it to Iomega, along with proper identification, a return authorization number obtained from the Iomega website or provided by the Iomega representative, and proof of purchase. Iomega will not protect, recover, or return data during warranty service, so you should duplicate your data before shipment.

Limitations

THE ABOVE WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. To the extent permitted by applicable law, IOMEGA SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Any implied warranty required by applicable law shall be limited in duration to the express warranty term. Some jurisdictions do not allow disclaimers of implied warranties or limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from jurisdiction to jurisdiction. Any suit for breach of any warranty on your product must be filed within one (1) year of the first date the suit could have been brought.

Open Source

The software included in this product contains copyrighted software that is licensed under open source agreements. Components of this software covered under GPL or other open source licenses are fully documented as to license and redistribution requirements in the ReadMe file provided with the software. A copy of this ReadMe may, at Iomega's discretion and subject to change at any time, be available on Iomega's Support and Download site at www.iomega.com/support. The corresponding source code will be delivered with the software or, at Iomega's discretion, made available for download. You may download the source code (when source code distribution is required) from the Iomega web site at www.iomega.com/support. To locate the download page for open source code, select your Iomega product and your operating system. Scroll down the page to the search field and enter open source. In addition, you can also obtain a copy of the applicable open source code on CD by sending a money order or check for \$10 (USD) to:

Iomega Corporation, ATTN: Source Code, 4059 South 1900 West, Roy, UT 84067 USA

Please include the model name for your Iomega product with the request.